

*USER MANUAL*

**WX 64**

## *Sixty-Four Channel Controller*



P/N: 77036023-1  
Revision: 1.1  
Reference Firmware: 1.03 (rev. 1.3.3)

**OLDHAM**  
*The Fixed Gas Detection Experts*



**THE INFORMATION CONTAINED IN THIS MANUAL IS ACCURATE TO OUR KNOWLEDGE.**

As a result of continuous research and development, the specifications of this product may be modified at any time without prior notice.

**IMPORTANT INFORMATION**

The modification of the material and the use of parts of an unspecified origin shall entail the cancellation of any form of warranty.

The use of the unit has been projected for applications specified in the technical characteristics. Exceeding the values cannot in any case be authorized.

**LIABILITY**

Neither Oldham nor any other associated company can be held liable for any damages, including, without limitations, damages for the loss or interruption of manufacture, loss of information, defect of the WX4 unit, injuries, loss of time, financial, or material loss, or any direct or indirect consequence of loss occurring in the context of the use or impossibility of use of the product, even in the event that Oldham has been informed of such damage.

**SAFETY INSTRUCTIONS**

Labels intended to remind you of the principal precautions of use have been placed on the unit in the form of pictograms. These labels are considered an integral part of the unit. If a label falls off or becomes illegible, see to it that it is replaced.



Warning: Read & understand contents of this manual prior to operation. Failure to do so could result in serious injury or death.



# Table of Contents

<b>SECTION - 1 GENERAL DESCRIPTION</b>	<b>9</b>
1.1 Important Safety Issues	9
1.2 General Description	10
1.3 Data Display Screens	10
1.3.1 Main Data Screen	10
1.3.2 24-Hour Trend Screen	12
1.3.3 Bar Graphs Screen	13
1.3.4 Combination Screen	15
1.3.5 Zone Screen	16
1.4 Specifications	17
1.4.1 DC Power Supply Requirements	17
1.4.2 Ambient Temperature Range	18
1.4.3 Humidity Range	18
1.4.4 Altitude	18
1.4.5 Housings	19
1.4.6 Non-Intrusive Magnetic Keypad	19
<b>SECTION - 2 BASIC OPERATION</b>	<b>21</b>
2.1 Main Menu Configuration	21
2.2 Changing Menu Variables Using The Keypad	29
2.3 Alarm Outputs	29
2.3.1 Standard Relay 1, 2 and 3	30
2.3.2 Horn/Piezo	32
2.3.3 Discrete Relay	33
2.3.4 Programmable Relay	34
2.4 Channel Configuration Entry Menu	34
2.4.1 Channel Configuration Menus	35
2.4.2 Alarm 1 / Alarm 2 / Alarm 3 Menu	36
2.4.3 Fault Alarm Menu	37
2.4.4 Data From Menu To Set Input Source	37
2.4.5 Linearize	41
2.4.6 Configure Menu	42
2.5 Communication Settings Menu	44
2.5.1 Com 1-4 Settings	45
2.5.2 ModBus TCP Settings	47
2.5.3 Network Settings	48
2.6 Security Menu	49
2.6.1 User Name	49
2.6.2 Lock Code	49
2.6.3 ModBus Lock Code	49
2.7 System Menu	49
2.7.1 Version	51
2.7.2 Configure	51
2.7.3 Zone Names	53

2.7.4	Mimic Mode	53
2.7.5	SD Card	54
2.7.6	View Event Log	55
2.7.7	Clear Event Log	56
2.7.8	View Sensor Life	56
<b>SECTION - 3 INPUT/OUTPUT BOARDS</b>		<b>59</b>
3.1	Main I/O Interface Board #10-0331	59
3.2	Input / Output Option Boards	60
3.2.1	Optional Analog Input Board #10-0334	61
3.2.2	Optional Discrete Relay Board #10-0345	62
3.2.3	Optional *Bridge Sensor Input Board #10-0347	63
3.2.4	Bridge Sensor Input Board Initial Setup	63
3.2.5	Optional 4-20mA Analog Output Board #10-0348	64
3.2.6	Optional Programmable Relay Board #10-0350	65
3.2.7	Optional 24 VDC 600 Watt Power Supply	66
3.2.8	Optional 24 VDC 150 Watt Power Supply #10-0172	68
<b>SECTION - 4 DIAGNOSTICS</b>		<b>69</b>
4.1	Standard Relays	69
4.2	Discrete Relays	70
4.3	Programmable Relays	70
4.4	Analog Inputs	71
4.4.1	View Inputs	71
4.4.2	Calibrate Board	71
4.5	Analog Outputs	72
4.6	Piezo	72
4.7	LEDs	73
4.8	Serial Ports	74
4.9	I/O Board Configuration	75
<b>SECTION - 5 ModBus</b>		<b>77</b>
5.1	ModBus TCP	77
5.2	ModBus Slave Writes	77
5.3	ModBus Slave Register Location	77
5.3.1	Coils	78
5.3.2	Discrete Inputs	78
5.3.3	Input Registers	81
5.3.4	Holding Registers	85
5.3.5	Standard Relay 1	87
5.3.6	Standard Relay 2	90
5.3.7	Standard Relay 3	93
5.3.8	Discrete Relays	96
5.3.9	Horn/Piezo	97
5.3.10	Channel Configuration	97
5.3.11	Programmable Relays	102

<b>SECTION - 6 ENCLOSURE OPTIONS</b>	<b>107</b>
6.1 Panel / Rack Mount Enclosure	107
6.2 NEMA 4X Wall Mount Fiberglass Enclosure	107
6.3 NEMA 7 Wall Mount Aluminum Enclosure	109
<b>SECTION - 7 WIRELESS OPTION</b>	<b>111</b>
7.1 Radio Setup Menu	112
7.1.1 Hop Channel	113
7.1.2 System ID	113
7.1.3 Mode	113
7.2 Wireless Monitor Mode	113
7.2.1 Radio Status Alarms - Wireless Monitor Mode	114
7.3 Wireless ModBus Slave Mode	115
7.4 Wireless ModBus Master Mode	115
7.5 Antenna Selection	115
7.5.1 Dipole And Collinear Antennas	115
7.5.2 Yagi Antennas	116
7.5.3 Mounting Near Other Antennas	117
7.5.4 Coax Cables	117
7.6 Surge Protection & Grounding	117
7.6.1 Antenna Grounding	118
7.6.2 Connections To Other Equipment	118
<b>SECTION - 8 WEBPAGE</b>	<b>119</b>
8.1 System Screen	120
8.2 Zone Screen	121
8.3 Channel Screen	122
8.4 Event Log Screen	123
8.5 Configure	124
8.5.1 Alarm Outputs	124
8.5.2 Channel Configuration	125
8.5.3 Copy Channels	125
8.5.4 Programmable Relays	126
8.5.5 System Configuration	126
8.5.6 Configuration Upload/Download	127
<b>SECTION - 9 TROUBLESHOOTING</b>	<b>129</b>
9.1 Channel Errors	129
9.1.1 Comm Error	129
9.1.2 Config Error	129
9.1.3 I/O Error	129
9.2 Reset To Factory Defaults	130





# SECTION - 1 GENERAL DESCRIPTION

## 1.1 Important Safety Issues

The following symbols are used in this manual to alert the user of important instrument operating issues:



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions.



This symbol is intended to alert the user to the presence of dangerous voltage within the instrument enclosure that may be sufficient magnitude to constitute a risk of electric shock.



### WARNINGS:

- **Shock Hazard** - Disconnect or turn off power before servicing this instrument.
- **WARNING- EXPLOSION HAZARD- DO NOT REPLACE FUSE UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.**
- **WARNING- EXPLOSION HAZARD- DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.**
- Use a properly rated CERTIFIED AC power (mains) cable installed as per local or national codes.
- A certified AC power (mains) disconnect or circuit breaker should be mounted near the controller and installed following applicable local and national codes. If a switch is used instead of a circuit breaker, a properly rate CERTIFIED fuse or current limiter is required to be installed as per local or national codes. Markings for positions of the switch or breaker should state (I) for on and (O) for off.
- Clean only with a damp cloth without solvents.
- Equipment not used as prescribed within this manual may impair overall safety.

## 1.2 General Description


The Oldham WX64 64 Channel Controller is designed to display and control alarm event switching for up to 64 sensor data points. It may also be set as a 16, 32 or 48 channel controller for applications needing fewer inputs. Three programmable standard alarms with features such as *ON* and *OFF* delays, *Alarm Acknowledge*, along with dedicated horn and fault relays make the WX64 well suited for many multi-point monitoring applications. Data may be input to the WX64 by optional analog inputs or via the multiple communication ports. These communication ports are programmable so the controller can be configured with multiple Master or Slave configurations. With a ModBus RTU *slave* RS-485 port configured, sending data to PCs, PLCs, DCSs, or even other WX64 Controllers is available. The Ethernet port allows the unit to be a ModBusTCP *Master and Slave* and also provides access to the embedded webpage. Options such as analog I/O and discrete relays for each alarm are easily added to the addressable I<sup>2</sup>C bus. Option boards have 16 channels and therefore require multiple boards for 64 channel applications.


In addition to traditional analog and serial methods of providing monitored values, the WX64 is also capable of sending and receiving wireless data.

A color 320 x 240 pixel graphic LCD readout displays monitored data as bar graphs, trends and engineering units. System configuration is through user friendly menus or via the internal webpage that can be accessed through the Ethernet connection built into the main I/O Board. All configuration data is retained in non-volatile memory during power interruptions and can also be backed up and loaded using the SD card located to the left of the display. The WX64 front panel is shown below in Figure1-1 displaying the Combination screen. Additional data screens are shown in section 1.

## 1.3 Data Display Screens

The WX64 Controller offers five distinct graphic displays for depicting the monitored data. These are Main Data, 24-Hour Trend, Bar Graphs, Zone and Combination

Screens. Pressing  from any of these display screens will bring you to the Main

Menu. Pressing  from the Main Data, 24-Hour Trend or Combination Screens will skip the Main Menu and bring you directly to the Channel Configuration Menu for the channel that is selected.

### 1.3.1 Main Data Screen

The WX64 Main Data screen shown below (Figure1-1) displays all active channels at once. It is capable of displaying 16, 32, 48 or 64 channels depending on the controller's configuration. This screen displays measurement name and uses a bar graph and colored cells that flash with new alarms to indicate alarm conditions. Once the alarms have been acknowledged by an operator, the cell will remain the appropriate color but will stop flashing, showing the alarm has been acknowledged. Utilizing the Display Alarm feature in the Systems Configuration menu allows new

alarms to always force the LCD to the Main Data screen. This is useful for applications requiring channels with new alarms to be displayed.










Figure1-1

While in the Main Data screen, use     to highlight any cell and press  to go directly to that channel's configuration menu or press  twice to scroll through that channel's individual data screens. The exploded channel 38 in the example below (Figure 1-2) indicates it is the channel selected, and unused channels are grayed out when turned off.





Figure 1-2  
Main Data Screen (64 Ch. Mode)

### 1.3.2 24-Hour Trend Screen

The WX64 24-Hour Trend screen shown in Figure 1-3 displays a 24-hour trend of input data for the channel selected. Vertical tick marks are each hour and horizontal tick marks are each 10% of full scale. Colored lines indicate alarm levels. The alarm level lines have triangles on the right end that indicate high and low trip for each alarm level. A triangle that points up represents a high trip alarm and one that points down represents a low trip alarm. Since each data point must be collected for several minutes before it may be displayed, it is likely input values will fluctuate during this interval. Therefore, MAX, MIN and AVERAGE values are stored in RAM memory for each subinterval. To accurately portray the trend, a vertical line is drawn between MIN & MAX values for each subinterval. The AVERAGE value pixel is then left blank, leaving a gap in the vertical line. This is demonstrated in the *noisy* area of the 24-hour trend in Figure 1-3. If the MAX & MIN values are within 2% of each other, there is no need for the vertical line and only the AVERAGE value pixel is darkened as in the *quiet* areas. If there is no trend data available, the corresponding section of the graph will be greyed out. This will occur on power interruptions.

The top portion of each trend screen indicates channel number, real-time reading in engineering units, measurement name, range, and MIN, MAX & AVERAGE values for the preceding 24-hour period. When a channel reaches alarm state, the colored bar changes to the color that represents that alarm level and flashes. Once the alarm is acknowledged, the bar stops flashing.




**Figure 1-3**  
**24-Hour Trend Screen**

### 1.3.3 Bar Graphs Screen

The WX64 Bar Graphs screen shown in Figure 1-4 allows 16 channels to be viewed simultaneously. Both engineering units and bar graph values are indicated in real time. Lines across the bars indicate the alarm trip points, making it easy to identify channels near alarm. The bar graph alarm lines have colored triangles on the bottom that indicate alarm level and high or low trip for each alarm. A triangle that points right represents a high trip alarm and one that points left represents a low trip alarm. When a channel reaches alarm state, the bar graph changes to the color that represents that alarm level and flashes. Once the alarm is acknowledged, the bar stops flashing. If there are more than 16 channels active, the scroll bar along the right side of the screen indicates channels not in the viewing area. If one of the channels not in the viewing

area goes into alarm, the scroll bar arrow flashes the corresponding color of the alarm, indicating which direction the user must scroll to display it. This is demonstrated by the top scroll bar arrow below.



**Figure 1-4**  
**Bar Graphs Screen**

### 1.3.4 Combination Screen

The WX64 Combination screen shown in Figure 1-5 offers a view of a single channel but displays the data as a 30-minute trend, bar graph and large engineering units. The bar graph and the background color change and flash indicating alarm condition. Once the alarm is acknowledged, they stop flashing. Colored lines across the bar graph and 30-minute trend indicate alarm levels. The alarm level lines have triangles on the right end that indicate high and low trip for each alarm level. A triangle that points up represents a high trip alarm and one that points down represents a low trip alarm. The Combination Screen is also useful for testing inputs for stability since MAX, MIN & AVERAGE values reset each time this screen is selected. For example, to test stability over a one-hour period for an input, begin timing as soon as the channel is selected. One hour later, record the MAX, MIN & AVERAGE values. The visible trend is only 30 minutes, but the difference between MAX & MIN indicates peak to peak excursions over the one-hour period and AVERAGE is the average for the hour. Longer or shorter tests may also be run. A blue vertical line is drawn on the screen when the screen is selected and moves to the left, indicating how long this screen has been active. The example below (Figure 1-5) has been active for 26 minutes.











Figure 1-5 Combination Screen

### 1.3.5 Zone Screen

The WX64 Zone screen displays the eight possible zones simultaneously. If an alarm condition occurs, the user will be able to quickly see in what zone the situation is occurring. Each active zone is divided into alarm levels, which are green until an alarm is present. Inactive zones and alarm levels are grayed out. If an alarm should occur, the zone name field will flash and the corresponding box in the assigned zone will turn the color of the alarm that is present or alternate if two different colors are present. Once the alarm has been acknowledged the name field will stop flashing. Utilizing the Display Alarm feature in the Systems Configuration menu allows new alarms to always force the LCD to the Zone screen. This is useful for applications requiring zones with alarms to be displayed. If the Zone feature is not utilized, this screen can be turned off in the Systems Menu.

The Zone screen is also helpful for configuring the different zones. To display all the channels included in any zone, press  while in the Zone screen. This will cause a blue box to outline one of the zones. Use  /  /  /  to select the correct zone and press  again. The Main Data screen will appear with all the channels that are included in the selected zone displayed in color and the channels that are not in the selected zone grayed out. Any channel needed to be included or excluded from the selected zone can be selected and configured from this screen.





**Figure 1-6**  
**Zone Screen**

## 1.4 Specifications

### 1.4.1 DC Power Supply Requirements

Standard WX64 power requirements are 10-30 VDC @ 12 watts applied to terminals 1 & 3(+) and 5 & 7(-) of TB4 on the standard I/O Board ([see section 3.0](#)). Optional features increase power consumption as described below:

- Discrete Relay Board option; add 6.5 watts per board (assumes all 16 relays are energized).
- Programmable Relay Board option; add 6.5 watts per board (assumes all 16 relays are energized).
- Analog Input Board option; add 1/2 watts per board plus transmitter power consumption.
- 4-20mA Output Board option; add 2.5 watts per board.

- Bridge Sensor Input Board option; add 3 watts max per board with eight 10-0192 modules installed (power consumption of the sensors not included).
- TB4 terminals 2, 4, 6 & 8 of the standard I/O Board provide a maximum of 500mA fused output power for powering of auxiliary external devices such as relays, lamps or transmitters. Power consumed from these terminals should be considered when calculating system power consumption.

#### 1.4.1.1 600 Watt AC – 24 VDC Power Supply

\*110-120 VAC @8.5A max

\*220-240VAC @ 5A max

\* Universal AC input automatically selects AC input range.

The 600 watt power supply (Figure 3-7) is for powering the WX64 and up to 64 detectors. This power supply can be paralleled with up to three additional 600 watt power supplies providing up to 2400 watts for applications with large power requirements. It also features a built in DC-OK signal and remote on-off control.

#### 1.4.1.2 150 Watt AC – 24 VDC Power Supply

\*110-120 VAC @3.2A max

\*220-240VAC @ 1.6A max

\* A slide switch on the front of the power supply selects AC input range.

The 10-0172 150 watt power supply (Figure 3-7) is for powering the WX64 and up to 64 detectors.

#### 1.4.1.3 Relays

The WX64 comes standard with five Standard SPDT 5A relays, consisting of one dedicated HORN and one dedicated FAULT relay plus 3 programmable alarm relays. Programmable relays provide voting logic for ALARM 1, ALARM 2, and ALARM 3. Discrete relays and additional Programmable relays are optional. All relays are rated at 5 Amp for 28 VDC and 250 ~VAC **RESISTIVE** loads.



**IMPORTANT:** Appropriate diode (DC loads) or MOV (AC loads) snubber devices must be installed with inductive loads to prevent RFI noise spikes. Relay wiring should be kept separate from low-level signal wiring.

#### 1.4.2 Ambient Temperature Range

-25 to 60 degrees C

#### 1.4.3 Humidity Range

0 to 90% R. H. Non-Condensing.

#### 1.4.4 Altitude

Recommended up to 2000 meters.


## 1.4.5 Housings

\*General purpose panel mount weighing 7 lbs and including hardware for 19" rack mounting (Figure 6-1).

\*NEMA 4X wall mount in fiberglass enclosure weighing 54 lbs (Figure 6-2).

\*Includes non-intrusive magnetic keypad.

## 1.4.6 Non-Intrusive Magnetic Keypad

The WX64 operator interface includes eight front panel *touch* keys .






. A magnetic keypad option offers these eight keys with adjacent magnetic keys. This option is included as a standard feature. It is useful in applications where it may be inconvenient to open the enclosure's door to access the *touch* keypad.




## SECTION - 2 BASIC OPERATION




The WX64 offers 5 graphic screens for viewing monitored data and several *Set-Up* menu screens for operator interface to configuration menus. The *Main Data* screen allows viewing of all active channels simultaneously. The *Trend* screen displays a 24-hour trend one channel at a time. The *Combination* screen displays a bar graph, large engineering units and a 30-minute trend one channel at a time. The *Zone* screen displays the eight possible zones simultaneously. Input channels may be displayed in


sequence from the *Trend* and *Combination* screens with    switches between the 5 graphic data screens. When WX64 power is applied, the graphic LCD starts in the *Main Data* screen.

### 2.1 Main Menu Configuration

Variables inside *Main* menu tree allow optimum WX64 configuration for a wide range of demanding multi-point monitoring applications. The main menu is entered by pressing

 *Channel configuration* menus are entered by pressing  from any channel's

data screens, and scrolling to the desired menu using  . Pressing  again enters the selected menu's tree of variables. This *Setup* mode may be exited

manually by pressing  or automatically when no keys are pressed for 5 minutes. Alarm relays and front panel alarm LED indicators remain active during the *Setup* mode. A Security menu offers a password feature to prevent tampering with WX64 parameters. See Figure 2-1 – Figure 2-7 for a complete WX64 menu tree layout.





Figure 2-1



**Figure 2-2**




Figure 2-3






Figure 2-4




Figure 2-5




Figure 2-6








Figure 2-7





## 2.2 Changing Menu Variables Using The Keypad


Upon entering a menu, a blue highlight bar controlled by / indicates the selected variable. Some are simple **YES/NO** or **ON/OFF** entries toggled by pressing

. Others, such as *Measurement Name* and *Eunits* fields may have many ASCII character possibilities. Allowed ASCII characters are as follows:


ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^\_`abcdefghijklmnopqrstuvwxyz{|}~ blank

space !"#\$%&`()\*+,-./0123456789:;<=>?@.  places a cursor over the item and

/ scrolls through each allowed entry. / move the cursor within a

field. When the field is complete,  clears the cursor and loads it into non-volatile

memory where it is retained indefinitely and  will cancel any changes that have

been made in the active field. With no cursor present,  closes open menus in reverse order and returns the LCD to the most recent data display.

## 2.3 Alarm Outputs

The menu item identified as **ALARM OUTPUTS** is accessed through the *Main Menu*. Selecting it allows users to configure the different types of outputs that can be connected to the WX64 controller through the menu shown in Figure 2-8. The variables under this menu are **STANDARD RELAY 1, STANDARD RELAY 2, STANDARD RELAY 3, HORN/PIEZO, DISCRETE RELAY** and **PROGRAMMABLE RELAY BOARD**.




Figure 2-8

### 2.3.1 Standard Relay 1, 2 and 3

Every WX64 comes standard with three programmable relays that users can individually program to suit their needs. This is achieved through the **STANDARD RELAY** menus accessed from the **ALARM OUTPUTS** menu. Only one Standard Relay menu screen is shown in Figure 2-9 because all the standard relay's menus are identical. Under the **STANDARD RELAY** menu, the user can configure the following.




Figure 2-9

### 2.3.1.1 A1 A2 & A3 Votes Required

**A1 Votes Required, A2 Votes Required & A3 Votes Required** are the number of A1, A2 & A3 level alarms that must be present for the relay to activate. This allows creation of logical AND function equations that control standard relays. Default settings for standard relay 1 are **A1 Votes = 01 A2 Votes = 00 & A3 Votes = 00**, which cause relay 1 to trip if any channel has an A1 level alarm active. Default settings for standard relay 2 are **A1 Votes = 00 A2 Votes = 01 & A3 Votes = 00**, which cause relay 2 to trip if any channel has an A2 level alarm active. Example: If either default setting is modified such that **A1 Votes = 02** and **A2 Votes = 01**, then any two channels must have an A1 level alarm active and any one channel must have an A2 level alarm active to trip that relay. **REMEMBER!** One of the A1s and the A2 could be on the same channel. These level alarms must come from a channel included in the **Zone** entry described below.

### 2.3.1.2 Acknowledge

Turning on **Acknowledge YES** allows the standard relay to be deactivated during alarm conditions by an **Alarm Reset**. This is useful if an audible device is being driven by the relay.

### 2.3.1.3 Failsafe

**Failsafe** controls relay activation for this standard relay. **Failsafe YES** causes the relay to de-energize during alarm conditions and energize when there is no alarm. Thereby, a power failure forces the relay contact to the alarm position. Note the standard Fault relay is always failsafe and may be monitored separately to indicate loss of power conditions in many applications.

### 2.3.1.4 Zone 1-8

**Zones** offer additional flexibility by controlling which channel zones trip this menu's standard alarm relay. There are eight possible zones that can be assigned to the relays individually. Some applications have different types of sensors, or sensors in different areas connected to the same WX64 Controller. In these cases, it may be undesirable for a sensor in one area to trip the same relay as a sensor in another area. The **Zone** menus may restrict this. For example, channels 1-32 might be set to trip

standard relay 1 while channels 33-64 trip standard relay 2. This is done by assigning channels 1-32 to zone 1 and channels 33-64 to zone 2 and turning only zone 1 to **YES** for Standard relay 1 and only zone 2 to **YES** for standard relay 2. Another possibility is channels 1-32 be set to trip standard relay 1 while channels 33-64 trip relays on an optional discrete relay PCB configured for Alarm 1 ([see section 3.2.2](#)).

### 2.3.1.5 Override Channels 1-8

**Override** allows entering one of the 256 different alarms that will trip this relay regardless of the **Votes** or **Zone** entries. There are four alarms per channel and 64 channels and any one of these alarms may be used as the override. This feature is useful when one channel's alarm has more significance than the others. Up to eight override alarms may be entered per relay.

### 2.3.2 Horn/Piezo

The WX64 is equipped with a low decibel audible piezo that chirps when keys are pressed and may be configured to audibly indicate alarm conditions. The standard horn relay is similar to the standard A1 & A2 relays.




Figure 2-10

#### 2.3.2.1 A1 A2 & A3

**Alarm 1, Alarm 2 & Alarm 3** menus control how this alarm level from each channel will affect the standard horn relay. Choices are **OFF**, **ON** or **BEEP** (one Hz. Pulsating). As an example, A1 conditions might pulse the horn (**BEEP**) and A2 conditions cause a steady horn (**ON**). Any other combination of these 3 choices is possible for A1, A2 and A3 levels affecting the horn relay. This feature is very useful since it allows the horn relay to serve as another level A1, level A2, level A3 or all three. Individual channel alarms may also be configured to not affect the Horn relay on a channel by channel basis ([see section 2.4.2.5](#)).

#### 2.3.2.2 Acknowledge

Turning on **Acknowledge YES** allows the Horn relay to be deactivated during alarm conditions by an **Alarm Reset**. This is useful if an audible device is being driven by the relay



### 2.3.2.3 Failsafe

**Failsafe** controls relay activation for this relay. **Failsafe YES** causes the horn relay to de-energize during alarm conditions and energize when there is no alarm. Thereby, a power failure forces the relay contact to the alarm position.

### 2.3.2.4 Piezo Alarm

**Piezo Alarm ON** causes the audible piezo to duplicate the action of the horn relay. This feature may be used to provide a low decibel indication of the status of the system's horn.

### 2.3.3 Discrete Relay

10-00345 Discrete relay options may also be configured to function in a *Failsafe* mode using the **ALARM OUTPUTS** menu shown in Figure 2-11. Entering **YES** causes these discrete relays to have energized coils when no alarm condition exists for the associated channel and de-energized coils when the alarm occurs. *Failsafe* is useful for indicating failed relay coils and loss of power conditions.




Figure 2-11

### 2.3.4 Programmable Relay

The 10-0350 Programmable Relay option board may be added if the user needs 16 more programmable relays in addition to the three standard relays. These 16 relays are configured through the **PROGRAMMABLE RELAY** menus accessed from the **ALARM OUTPUTS** menu shown in Figure 2-12. Only one Programmable Relay menu screen is shown because all the Programmable relay's menus are identical. Under the **PROGRAMMABLE RELAY** menu, the user can configure the same parameters as **STANDARD RELAYS** discussed in [section 2.3.1](#).







Figure 2-12

## 2.4 Channel Configuration Entry Menu

**CHANNEL CONFIGURATION** is accessed through the **MAIN MENU**. Once in the

**CHANNEL CONFIGURATION** entry menu, shown on the left in Figure 2-13, use 

 to scroll up or down to select the channel that is to be configured. Once the

correct channel is selected,  brings you to that channel's configuration menu, shown on right below. These items affect only the specific channel selected. *System* specific variables are accessed through the **MAIN MENU** shown in Figure 2-1.




Figure 2-13

## 2.4.1 Channel Configuration Menus

Once the appropriate channel has been selected, its configuration menu allows the following parameters to be accessed: **Alarm 1**, **Alarm 2**, **Alarm 3**, **Fault Alarm**, **Data From**, **Linearize** and **Configure**.




Figure 2-14

## 2.4.2 Alarm 1 / Alarm 2 / Alarm 3 Menu

The **ALARM MENU** parameters are listed only once, because alarms 1, 2 and 3 are identical, except A1 does not have the option to change the color; it is always yellow, and only A3 can be turned off if not needed. The following parameters can be accessed while in the **ALARM MENUS**.

Channel 38 Config	
Alarm 1	~
Alarm 2	~
Alarm 3	~
Fault Alarm	~
Data From	~
Linearize	~
Configure	~

Ch. 38 Alarm 3	
Set Point	60
Latching	No
Trip On	High
On Delay (sec)	0
Off Delay (min)	0
Horn Drive	Yes
Color	Red
Enabled?	No

Figure 2-15

### 2.4.2.1 Setpoint

**SETPOINT** is the value where the alarm trips. It is entered in engineering units. For example, if a channel monitors 0-50 ppmH<sub>2</sub>S and the alarm must trip at 10 ppm, the correct entry is 10.00.

### 2.4.2.2 Latching

**LATCHING** determines either manual or automatic alarm reset operation. **YES** requires a manual **Alarm Reset** to unlatch the alarm even though an alarm condition no longer exists. **YES** also causes this alarm group's common relay, front panel LED and optional discrete relay to latch. **NO** allows all outputs for this alarm to automatically reset as soon as the alarm condition clears.

### 2.4.2.3 Trip On

**TRIP ON** is set to **HIGH** for increasing alarms or **LOW** for decreasing alarms to determine if the alarm activates upon exceeding or falling below the setpoint.

### 2.4.2.4 On/Off Delays

The **ON DELAY / OFF DELAY** entries allow **ON** and **OFF** time delays affecting how long the setpoint must be surpassed before an alarm event transition occurs. **ON** delays are limited to 10 seconds while **OFF** delays may be as long as 120 minutes. Delays are useful in many applications to prevent nuisance alarms and unwanted cycling into and out of alarm conditions.

### 2.4.2.5 Horn On

The **HORN ON** entry allows linking this alarm to the common horn relay. **NO** causes the alarm to have no effect upon the horn relay. Entering **YES** causes this alarm to turn the horn relay on steady, or, to pulse it depending upon horn configuration in the system menu ([see section 2.3.2.1](#)).

### 2.4.2.6 Color

**COLOR** gives the option of assigning A2 or A3 alarms different colors besides the default RED. The options are RED BLUE and ORANGE.

### 2.4.2.7 Enabled

**ENABLED?** Is for Alarm 3 only. Because most applications require only two alarm levels, A3 is turned **NO** (off) from the factory. **YES** activates the A3 alarm level if needed.

## 2.4.3 Fault Alarm Menu

The channel alarm identified as Fault activates when the input is out of range in the negative direction. The fault level is always low trip and the dedicated common fault relay is always failsafe. The minimum setting is -10% of full scale. The factory default setting is -10, which is -10% of 100 or default full scale value. If the full scale value is changed, the fault value is automatically updated to reflect the new value. For example, if the fault level is -10 and the full scale value is changed from 100 to 50, the fault level will automatically change to -5, which is -10% of the new full scale value. If the fault level is -5 (-5% of full scale) and the full scale value is changed from 100 to 50, the fault level will automatically change to -2.5 which is -5% of the new full scale value.




Figure 2-16

## 2.4.4 Data From Menu To Set Input Source

Channels may be independently configured to accept input data from the following sources:

- An analog input PCB attached to the I<sup>2</sup>C bus. These include *Analog and Bridge* input boards.
- ModBus RS-485 from up to four configured master ports connected to ModBus slave devices.
- ModBus TCP/IP connected to the Ethernet port.

**Note:** Each *ModBus* menu selection also requests the RTU # and the Alias register # location of the data to be retrieved from the RTU. Alias register

numbers define the location of the variable representing the input value and must be obtained from the manufacturer of the ModBus RTU device.

- One of our Radio Modem kits may be connected to the ModBus RS-485 master port to enable wireless communication to OLCT 200/RF wireless sensor transmitters. [See section 7.2.](#)

Channel's inputs are configured using the following parameters in the **DATA FROM MENU**.




Figure 2-17

### 2.4.4.1 Source



toggles the **SRC** or source entry between *Analog, ModBus 16bit, ModBus 16bit Signed, ModBus 32bit, Wireless Monitor, and Digital Input*. This parameter tells the WX64 where the information to be displayed comes from. Each 16 channel group can have multiple sources. For example if an application needs 12 4-20 inputs and 52 ModBus inputs, the first 12 channels can be programmed for *Analog* input and the last 52 channels can be programmed to accept the ModBus inputs. For ModBus 16bit, a single register will be interpreted as an unsigned 16bit integer. For ModBus 16bit signed, a single register will be interpreted as a signed 16bit integer. For ModBus 32bit, 2 consecutive registers are read and interpreted as a 32bit IEEE Floating Point value. In 32bit Mode, the register value is read directly and not scaled with Min/Max Raw parameters.

### 2.4.4.2 Min Raw & Max Raw

**MIN/MAX RAW** is the Min Raw and Max Raw counts entries included in Input Data From: menus define the range of input counts that provide *Measurement Range* read-out values described in [section 2.4.6.2](#). This menu entry is determined by the A/D converter resolution of the channel's input. For example, if the input is a 10 bit ModBus device with zero at 200 counts and 100% at 1000 counts, then this menu's MIN should be set at 200 and MAX at 1000. If communicating with the WX64's optional 12 bit Analog Input PCB, the MIN should be 800 and the MAX 4000.

If the input device's resolution is unknown, the live counts variable on the Combination screen displays actual raw A/D counts currently being read by this channel. This reading may be used to test the input device for what A/D counts are provided for zero and 100% if these values are unknown. Forcing the input device to read zero should

provide the A/D counts value needed to make this channel's display also read zero. Likewise, forcing the input device to read 100% should provide the A/D counts value needed to make the WX64 channel's display also read 100%.

Note: Each *Data From:* item has a matching default Min/Max counts value of 20% to 100% with  $\pm 5\%$  over/under range applied. If the default value is incorrect for the input device, it should be edited.

#### 2.4.4.3 Filter Sample Count

The **FILTER SAMPLE COUNT** is the number of samples from an Analog Input channel that are averaged together before displayed. The valid range is 1-40 with the default value of 10. If a channel has a noisy input the sample rate can be increased, causing the noise to average itself out. This higher number of samples causes the channel to react slower to input.

#### 2.4.4.4 Local Cal

**LOCAL CAL** is available with the Analog Input option. There are three choices *Board Default, On, and Off*. With the Analog Input option used for both the Analog and Bridge input boards, *Board Default* automatically turns the local calibration feature **On** for the Bridge input and **Off** for the Analog Input. If there is a need to calibrate a channel locally and the board default is **Off** it can be manually changed.

WX64 CAL MODE features allow pushbutton calibration of zero and span values. This feature should be utilized only when there are no other zero/span controls within the monitoring system since it is inappropriate to calibrate a signal at more than one point. Therefore, if calibration is to be performed at another transmitter or monitoring device, the WX64 CAL MODE feature should not be used.

The CALIBRATION MENU allows entering the correct **Cal ZERO & Cal SPAN** setpoint values needed to calibrate the sensor. These are entered in the same engineering units as input range. **Set Zero & Set Span** controls in this menu allow pushbutton calibration by moving the highlight bar to each and pressing the **EDIT** key. A live reading of the channel's value in the tool tip box allows calibration checks to see if an adjustment is needed. Unintentional calibrations are reset by the **Set Unity Gain** menu item. **Set Unity Gain** resets zero offset to 0 and span gain to 1. It is useful for returning the calibration to a known starting place. Sensor aging may be monitored by recording zero and span readings at **Unity Gain** when it is new, and again at later dates when degradation may have occurred.

To check zero calibration, apply the ZERO calibration value to the sensor and observe the live reading. If the zero reading differs from the zero setpoint, a calibration is needed. To calibrate zero, move the highlight bar to **Set Zero** and press **EDIT**. A warning message explains that pressing **EDIT** again will change the zero calibration and any other key will exit. The procedure for span calibration is identical. For example, if an LEL combustible sensor is to be spanned with 50% LEL span gas, the span setpoint must be 50%. If 45% LEL is to be used later, the span setpoint must be changed to 45% to match the span calibration gas. If the reading is only 40% LEL with the 50% gas applied, a span calibration is needed. Move the pointer to the **Set Span** entry and press **EDIT** twice. **Unity Gain** may be used at any time to cancel incorrect calibrations and start again.

### 2.4.4.5 Marker Menu

Some transmitters or monitoring devices providing WX64 inputs also indicate special modes of operation, such as *Calibration*, *Maintenance* or *Fault*, by transmitting a special <4mA or negative “Marker” value. The WX64 offers channel Marker menus for detecting and indicating such events (see Figure 2-18). While active, the WX64 displays a 6-digit ASCII message to indicate the special event and if equipped with 10-0348 4-20mA output option, the WX64 also transmits the same <4mA value.




Figure 2-18

#### 2.4.4.5.1 Marker Enabled

Turns the marker feature ON and OFF.

#### 2.4.4.5.2 Marker %

The negative Marker value is entered into the **Marker %** field as a negative percent of full scale. For example, -15.62% of full scale detects a marker value of 1.5mA (1.5mA is -15.62% of full scale when 4-20mA is the range). Marker mode is active when the input value reads the Marker %  $\pm 1\%$  of full scale.


#### 2.4.4.5.3 Mark As

The **Mark As** menu allows user entry of the 6-digit ASCII message to be displayed when the marker is detected.

#### 2.4.4.5.4 Sensor Life

**Sensor Life** should only be activated when the Marker event is *Calibration* and when a sensor life value is transmitted after each calibration. This feature is provided primarily for use when interfacing the WX64 to Oldham's OLCT 200 Sensor Transmitters, which may be configured to transmit sensor life values after each calibration (Figure 2-19). For **Sensor Life** to record properly the monitor must perform as follows: After the *Calibration* Marker interval, 4.0mA transmits for 10 seconds to indicate its *calibration mode* is complete. The monitor then transmits between 4.0mA and 5.0mA for five seconds depending on remaining sensor life where 4.0mA = 0% and 5.0mA = 100% remaining sensor life. The WX64 reads this value and records it as the channel's **Sensor Life**. **Sensor Life** is stored in the WX64 ModBus database and displayed as a bar graph in the Sensor Info screen ([see section 2.7.7](#)). It is a useful tool for planning sensor replacement schedules.





**Figure 2-19**

#### 2.4.4.6 Remote ID

When the Data From is set to receive input through the Communications ports, this is where the salve's unique ID number is entered. Remote ID numbers up to 247 are valid.

#### 2.4.4.7 Alias

The *Alias* register numbers define the location of the variable representing the input value of the ModBus data received through the Communications ports. This number must be obtained from the manufacturer of the ModBus RTU device.

#### 2.4.4.8 Interface

The *Interface* assigns what communication port the ModBus slave or Wireless radio is connected to and the channel it will get its data from. The communication port that is assigned here must be configured as a ModBus Master or Wireless Monitor in the Communications Menu ([see section 2.5.1](#)).

#### 2.4.4.9 Slave Byte Order

If ModBus 32bit is selected, a Byte Order entry appears at the bottom of the menu. This determines WORD and BYTE alignment of data at the remote ModBus transmitter when sending its 4 byte IEEE Floating Point values. With the select bar on this entry, the EDIT key toggles between the 4 possible modes.

### 2.4.5 Linearize

The linearization menu allows each channel to have its own linearization curve stored in the controller's non-volatile memory. Input versus output points must be entered in percent of full scale values. This means if the range is 0-200 ppmH<sub>2</sub>S, then 100 ppm is 50% of full scale. Zero input will provide a zero output and 100% input a 100% output. Nine intermediate points may be entered to define the curve.

Channel 38 Config	
Alarm 1	~
Alarm 2	~
Alarm 3	~
Fault Alarm	~
Data From	~
Linearize	~
Configure	~

Ch. 38 Linearize		
Input	Output	
10.00	10.00	
20.00	20.00	
30.00	30.00	
40.00	40.00	
50.00	50.00	
60.00	60.00	
70.00	70.00	
80.00	80.00	
90.00	90.00	

Figure 2-20

## 2.4.6 Configure Menu

From the entry level setup menu in Figure 2-14, the CONFIGURE menu may be entered for setting variables defining how the controller presents monitored data to the various graphic displays.

Channel 38 Config	
Alarm 1	~
Alarm 2	~
Alarm 3	~
Fault Alarm	~
Data From	~
Linearize	~
Configure	~

Ch. 38 Configure		
Info	Measurement	Name
Engineering Units	PCTLEL	
Zero		0
Span		100
Decimal Points		0
Channel On?		Yes
Zone		1
Deadband (%)		1
Copy To Channel		~
Copy To Group		~
Restore Ch. Defaults		~

Figure 2-21

### 2.4.6.1 Info / Measurement Name

The first two items in this menu are for entering the 16 character *Measurement Name* and 6 character *engineering unit* ASCII fields. Eunits should define the units of measure for what this channel is to display. *Measurement Name* should describe the source of this data in the user's terminology. [Section 2.2](#) of this manual describes how to use the front keypad to modify these fields.

### 2.4.6.2 Zero / Span

The **ZERO / SPAN** entries allow configuration of the measurement range displayed by this channel. Measurement Range works along with *A/D Counts* menus, described in [section 2.4.4.2](#), to define the range of the input signal's engineering units. For example, if a channel's input is 4-20mA from a transmitter monitoring 0 to 10ppm chlorine, then the **Zero** value should equal 0.000 and the **Span** value equal 10.00. The six ASCII engineering units previously entered are automatically displayed at the top of each menu as a reminder. Four digits must appear in this entry, so trailing 0's may appear here that are not displayed on other data screens.

### 2.4.6.3 Decimal Points

Resolution of displayed channel values is configured in this menu by setting the number digits trailing the decimal point. Values are limited to a maximum of four digits, and a polarity sign. An auto-ranging feature displays the highest resolution allowed by this menu's decimal point entry. For example, if three decimal points are entered, and the range is 0 to 100ppm, the reading will be **0.000** at 0ppm and **100.0** at 100ppm. However, this may be undesirable due to the high resolution at zero unless the sensor's output is extremely stable. If decimal points are limited to one, the 0ppm reading becomes **0.0** and the 100ppm reading remains **100.0**. Resolution may be limited further by setting decimal points to 0. In the above example, this would cause 0ppm to display **0** and 100ppm to display **100**.

### 2.4.6.4 Channel On?

The **Channel On?** entry determines if this channel is to be utilized. Turning it off will cause the controller to never process inputs applied to this channel and no alarms will be tripped or data displayed. Inactive channels will be grayed out on the Main Data screen and skipped when scrolling through the 30-Minute Trend screens. Channels may be turned off in groups of 16. This is done in the System Setup menu described in [section 2.7.2.4](#).

### 2.4.6.5 Zone

The **ZONE** feature allows assigning of channels into up to eight possible **ZONES**. This is useful for applications that may need all alike gases or inputs from a certain area to be grouped together. Once the channels are assigned to a certain group, relays can be configured to respond to only the channels in this ZONE ([see section 2.3.1.4](#)).

### 2.4.6.6 Deadband

DEADBAND allows forcing low values to continue to read zero. This is useful when there are small amounts of background gases that cause fluctuating readouts above zero. The highest amount of deadband allowed is 5%. The 4-20mA output is affected by this menu item and will remain at 4mA until the input gets above the programmed deadband level.

### 2.4.6.7 Copy to Channel

This menu simplifies the Setup procedure by allowing similar channels to be copied from one to another. For example, if some channels are identical except for the *Measurement Name* entry, one channel could be configured and copied to the other channels that are the same. Only *Measurement Name* then must be configured on the

copied channels. Use  and /  to select channel numbers and  once more to copy.

### 2.4.6.8 Copy to Group

This menu simplifies the Setup procedure by allowing one channel to be copied to a whole group of channels. For example, if some groups of 16 channels are identical except for the *Measurement Name* entry, one channel could be configured and copied to the whole group at one time. Only *Measurement Name* then must be configured on

the copied channels. Use  and /  to select the group to be copied then  point to **Copy Now?** Press  once more to copy.

### 2.4.6.9 Restore Ch. Defaults


This menu allows the user to reset a specific channel to factory defaults without affecting any other channels. This is useful if a channel must be changed to a different input. All channel configurations will be reset, and the user can configure the new parameters from the factory defaults. A confirming dialog box will appear before the channel is reset, protecting against an accidental restore.

## 2.5 Communication Settings Menu

**COMMUNICATION SETTINGS** menu is accessed through the **MAIN MENU**. This menu is used to configure the four possible communication ports. Once in the **COMMUNICATION SETTINGS** entry menu, shown on the left in Figure 2-22, use



to scroll up or down to select the communication port that is to be

configured. Once the correct com port is selected,  brings you to that com port's configuration menu, shown on the right below. Com ports 1-4 have identical menus and are shown only once.




Figure 2-22

### 2.5.1 Com 1-4 Settings

The four ModBus RS-485 ports can be individually configured multiple ways using the following menus.




Figure 2-23

### 2.5.1.1 Function

The Function parameter allows the communication ports to be set as ModBus Master, ModBus Slave, Wireless Monitor, Redundant Port or Disabled.

#### **ModBus Master**

Master mode allows the communication port to poll any device using the ModBus RTU protocol. This setting is also utilized for Wireless ModBus Master. [See section 7.4.](#)

#### **ModBus Slave**

Slave mode allows the communication port to be polled by any ModBus Master device using the ModBus RTU protocol. This setting is also utilized for Wireless ModBus Slave. [See section 7.3](#)

#### **Wireless Monitor**

This mode is exclusively for wireless communication to Oldham's OLCT 200 wireless sensor transmitters [See section 7.2.](#)

#### **Redundant Port**

This setting allows the user to create a redundant port which uses the settings from another port that is already configured. Redundant mode works with ports configured as **ModBus Master**. When configured as a redundant port, the **Primary** port communicates until it gets a communication error. The WX64 then switches to the redundant port and continues to poll the slave nodes. When communication has switched to the redundant port, the WX64 trips the **Fault** relay, beeps, and displays a warning telling the user there has been a communication error. The user is able to **Ignore** the warning for 12 hours or **Test** the **Primary** port. Ignoring the problem gives technicians time to troubleshoot and fix the problem. If the problem is not going to be fixed, the warning message can be cleared permanently by disabling the redundant port. If the user chooses to test the port and it passes, a success message will appear and the error message will be cleared.

Before a Primary port switches to its redundant port, a scan must fail 3 times. All channels set up to use the primary port are polled. At the end of the scan, if an error has occurred on any channel, the error count is incremented. After 3 scans fail, the redundant port takes over communication. If the redundant port also fails 3 times, communication is switched back to the primary port. When both ports fail, the WX64 will continuously switch between primary and redundant port.

Individual channels do not enter **COMM ERROR** mode unless both primary and redundant port failures occur.

Manual test can be performed on the redundant or primary port by going into the redundant port's com setting menu and selecting **TEST REDUNDANT PORT** or **TEST PRIMARY PORT**. While in this menu the WX64 also gives the active port on the screen.

#### **Disabled**

Select Disable to turn the port off if not needed.

### 2.5.1.2 Baudrate

This setting allows user to set the data rate of the communication port. The options include **9600**, **19200**, **38400**, **57600** and **115200**.

### 2.5.1.3 Timeout

The Master **TIMEOUT** menu item affects the WX64's *master* ModBus ports. **TIMEOUT** is the length of time in milliseconds the controller waits before a ModBus request fails. Three consecutive failed requests must occur before a communication error is indicated. This item is useful for optimizing throughput to the WX64 from other slave RTUs.

### 2.5.1.4 Poll Delay

The time in milliseconds the unit will delay between ModBus master requests.


### 2.5.1.5 Radio Setup

**RADIO SETUP** is used to configure radio kits that are connected directly to the WX64. [See section 7.1](#).

### 2.5.1.6 Slave Byte Order

If ModBus Slave is selected, a **BYTE ORDER** entry appears in the menu. This determines WORD and BYTE alignment of data at the remote ModBus transmitter when sending its 4 byte IEEE Floating Point values. With the select bar on this entry,




the  toggles between the 4 possible modes. Min / Max Raw values are not used in this mode.

### 2.5.1.7 Wireless Timeout

If Wireless Monitor is selected, a **WIRELESS TIMEOUT** entry appears in the menu.



The  toggles between 1m, 6m, 12m and 18m. These represent the number of minutes the WX64 will wait before going into COMM. ERROR. [See section 7.2.1](#).

## 2.5.2 ModBus TCP Settings





Figure 2-24

### 2.5.2.1 Slave Byte Order

If ModBus Slave is selected, a **BYTE ORDER** entry appears in the menu. This determines WORD and BYTE alignment of data at the remote ModBus transmitter when sending its 4 byte IEEE Floating Point values. With the select bar on this entry,



the  toggles between the 4 possible modes. Min / Max Raw values are not used in this mode.

### 2.5.2.2 Master Timeout

The time in milliseconds before the unit gives up on a ModBus request and moves on to the next channel. After three consecutive timeouts, the channel enters the COM Error state.

### 2.5.2.3 Master Poll Delay

The time in milliseconds the unit will delay between ModBus master requests.

## 2.5.3 Network Settings




Figure 2-25

### 2.5.3.1 DHCP Enabled

Enable this parameter to allow the IP address to be set automatically by an external DHCP server. When this parameter is enabled, the unit can be accessed by its hostname or IP address, although the IP address will be dependent on the DHCP server and could potentially change.

### 2.5.3.2 Hostname

When DHCP is enabled, hostname identifies the unit on a network instead of IP address. This feature requires an external DHCP/DNS server to be present. The hostname does not apply when DHCP is disabled.

### 2.5.3.3 IP Address

IP address identifies the unit on a network. This is automatically set when DHCP is enabled.

### 2.5.3.4 Netmask

Specify if your network requires. Netmask specifies the subnet addressing scheme. This is automatically set when DHCP is enabled.



### 2.5.3.5 Gateway

Gateway is the IP address of the device that may connect this subnet to other networks. This is automatically set when DHCP is enabled.

## 2.6 Security Menu

A password entered in the **SECURITY** menu allows locking all menus. *Viewing* menus is not denied but attempts to *edit* variables flashes the **Locked** message on the LCD.




Figure 2-26

### 2.6.1 User Name

Authorized individuals locking the system should first enter a name, phone number or other contact information into the 10-digit field so they can be contacted to unlock the unit at a later date.

### 2.6.2 Lock Code


To lock or unlock the system, the correct 4-digit authorization number must be entered into the **Lock Code** field. The WX64 will ask this 4-digit code to be re-entered and then it will be locked. Once locked, re-entering the code will unlock the unit. It is very important to record the 4-digit code. However, if lost, the controller may be unlocked by entering the override code: **8621**

### 2.6.3 ModBus Lock Code

The ModBus database is normally locked. The register 40099 is used to unlock the unit and allow writes. When written with the unlock code (found in the security menu), the database unlocks and stays unlocked while writes occur and for 10 minutes of being idle. The default ModBus lock code is **1234**.

## 2.7 System Menu

The **SYSTEM** menu is accessed through the **MAIN MENU**. Some items needing configuration are not specific to a channel but affect the entire WX64 system. These are located in the system entry menu shown in Figure 2-27. System menus are

accessed by pointing to the desired item and pressing .




Figure 2-27

## 2.7.1 Version


The **VERSION** line in the System menu displays the version of firmware that is programmed in the controller.

System	
Version	v 1.00
Configure	~
Zone Names	~
Mimic Mode	~
SD Card	~
View Event Log	~
Clear Event Log	~
View Sensor Life	~

Figure 2-28

## 2.7.2 Configure

Some items needing configuration are not specific to a channel but affect the entire WX64 system. These are located in the **CONFIGURE** entry menu shown on the right side of Figure 2-29. System Configuration menus are accessed by pointing to the

desired item and pressing .

System	
Version	v 1.00
Configure	~
Zone Names	~
Mimic Mode	~
SD Card	~
View Event Log	~
Clear Event Log	~
View Sensor Life	~

Configure	
Name	Controller 1
Contrast	50
Date	10 / 20 / 2010
Time	09:43:28
Enable Channel Count	64
Display Alarm	Main Data
Warmup Time (min)	1
Cal Purge Time (min)	1
Zone Screen Enabled	Yes
Block Negative	Yes

Figure 2-29

### 2.7.2.1 Name

Assign the controller a name for use in the backup configuration file name on the SD card. The controller name is limited to 16 characters.

### 2.7.2.2 Contrast

The Configure menu item identified as **CONTRAST** allows users to adjust the LCD contrast to a level suitable to the ambient lighting. Selecting **CONTRAST** and pressing



causes the



keys to increase and decrease LCD contrast.

### 2.7.2.3 Date & Time

Adjust the date and time here for use in DATA and EVENT LOGGING. This is a factory setting but may need to be adjusted for the end user's location.

### 2.7.2.4 Enable Channel Count

For applications that do not need **64** channels, the WX64 can be configured to display **16, 32** or **48**. With fewer channels to be displayed in MAIN DATA screen, the cells expand for better resolution.

### 2.7.2.5 Display Alarm

Utilizing the display alarm feature in the System menu allows the WX64 controller to force the LCD to the MAIN DATA or ZONE screens when an alarm level is reached. This proves to be useful if channel or zone must be displayed when in alarm. The MAIN DATA screen is the default alarm screen from the factory.

### 2.7.2.6 Warmup & Cal Purge Time

**WARMUP & CAL PURGE TIME** are available to prevent unwanted alarm trips during these times. This time can be adjusted up to five minutes for sensors that take a long time to warm up or drift back down after a calibration.

### 2.7.2.7 Zone Screen Enabled

In some applications, all points are linked together in one large ZONE, so the ZONE screen does not need to be displayed. Turning **ZONE SCREEN ENABLED** to **NO** causes scrolling through the screens to skip the ZONE screen.

### 2.7.2.8 Block Negative

This setting prevents negative channel values from being displayed. It applies to all channels.

### 2.7.3 Zone Names

ZONES 1-8 names can be edited for a quick reference while in the zone screen. These 16 character names show up in the title bar of each zone.




Figure 2-30

### 2.7.4 Mimic Mode

When mimic mode is enabled, the WX64 will duplicate the data and alarms of another WX64, which can be connected with RS485 or TCP/IP. Entering the communications port and slave ID allows the WX64 to automatically retrieve programmed configuration parameters from the Main controller. The Mimic controller's communication port must be configured as the ModBus Master and the Main controller's communication port is set to ModBus Slave. Once connected, the Mimic controller will update automatically one minute after any parameter is changed in the Main controller.




Figure 2-31

## 2.7.5 SD Card

A two gigabyte SD card comes standard with each WX64. This SD card is not needed for normal operation, but is useful for data logging and backing up configuration.

When the data logger is enabled, every ten minutes the Min, Max, Average, Alarm 1/2/3 status, Fault status, Calibration status and Alarm reset for each active channel is written to the SD card in one-minute intervals. The log files are stored on the SD card by date. Each day a new file is created and stored in a directory structure as follows:

**UNIT\_NAME\YEAR\MONTH\DAY.csv**. The files are comma delimited text files and work with MS Excel, which can be used to create historical plots of the data.

The first line in the file contains a date stamp. The next line is the header. The header shows the name of each column. The AVG fields in the header list the zero and span values for that channel. The zero and span can be used when creating plots. Another line exists for each minute of the day. Those lines are time stamped with the hour and minute.

The numeric format of the MIN, MAX and AVG values are based on channel settings. The decimal precision is the same that is viewed from the unit. This can be adjusted with the decimal points parameter in each channel's Configure menu.

The SD Card can store more than 1 year of historical data, but backups of the card should be performed on occasion. Backing up logs requires removing the SD card and inserting it in a PC that has a card reader interface.

The figure shows two screenshots of the WX64 menu. The left screenshot is titled 'System' and lists various menu items with a tilde (~) next to them. The right screenshot is titled 'SD Card' and shows the status of the SD card and logging options.

System	
Version	v 1.00
Configure	~
Zone Names	~
Mimic Mode	~
SD Card	~
View Event Log	~
Clear Event Log	~
View Sensor Life	~

SD Card		
Card Status	OK	
Logger Enabled		YES
Save Config File		~
Load Config File		~
View Log File Trend		~

Figure 2-32

### 2.7.5.1 Card Status

When the SD card is properly inserted into the card slot, **CARD STATUS** will display **OK**. If the SD card is removed or becomes corrupt, the green LED (Figure 1-1) will blink continuously and **CARD STATUS** will say **CARD NOT FOUND**.

### 2.7.5.2 Logger Enabled

Enabling the Data Logger allows the WX64 to record the channel data for all active channels.

### 2.7.5.3 Save Configuration File



By selecting **SAVE CONFIG FILE**, the current configuration file will be backed up on the SD card. This can be beneficial in the event of a board failure or if multiple WX64s must be programmed the same. The filename of the saved will be **UnitNameDDMMYY.cfg** where DDMMYY is the current date. Saving configuration will overwrite previous saves from the same date. It is recommended to back up configuration once a unit is fully configured.

### 2.7.5.4 Load Configuration File

Once a file is backed up on the SD card, it can be loaded back into the WX64 to change the current configuration to a previous configuration, or the SD card can be moved to another unit and the configuration can be copied to the second unit. This is done by selecting **LOAD CONFIG FILE** then selecting the name and date of the configuration file that is to be copied.



### 2.7.5.5 View Log File Trend

**VIEW LOG FILE TREND** displays historic 24 hours of data using the 24-Hour Trend screen format shown in Figure 1-3. The user selects the date to be displayed and all

active channels for that day are loaded into the WX64. Use the /  to scroll through the 64 channels of historic data. The WX64 24-Hour Historic Trend data screen is identified by the cyan background color in the graph area. All alarm processing is active during viewing of historic trend, and if a new alarm becomes present, a prompt will ask the user if s/he would like to continue viewing the historic data or exit this mode and view real time readings.

### 2.7.6 View Event Log

The WX64 logs the last 255 events, first in first out, in non-volatile memory so a SD card is **NOT** necessary to view the event log. The events are time and date stamped,

and if channel specific, the number is shown in the right column. Use /  to scroll through the events.

The following events are logged: Alarm 1 In, Alarm 1 Out, Alarm 2 In, Alarm 2 Out, Alarm 3 In, Alarm 3 Out, Fault In, Fault Out, Comm Error, Config Error, Cal In, Cal Out, System Boot and Cold Boot.




Figure 2-33

## 2.7.7 Clear Event Log

After initial setup and testing of the controller, **CLEAR EVENT LOG** is used to manually clear all events in the log file. If the event log is not cleared, the older events will be pushed out as new ones occur.




Figure 2-34

## 2.7.8 View Sensor Life

**Sensor Life** is available when at least one channel has **Sensor Life** activated in the **Marker menu** (see section 2.4.4.5). The **Sensor Info** screen displays each channel's sensor status as illustrated in Figure 2-35. Channels with **Sensor Life** disabled are indicated by **Ch. # Disabled** below the bar. **Cal Required** indicates no Calibration Marker value has been received by the WX64.



System	
Version	v 1.00
Configure	~
Zone Names	~
Mimic Mode	~
SD Card	~
View Event Log	~
Clear Event Log	~
View Sensor Life	~

Measurement	% Oxygen	Measurement	% Oxygen
Measurement	Measurement	Measurement	Measurement
Measurement	Measurement	Measurement	Measurement
Measurement	ppm H2S	Measurement	Measurement
Measurement	Measurement	Measurement	Measurement
Measurement	Measurement	Measurement	Measurement
Measurement	Measurement	Measurement	Measurement
Measurement	Measurement	Measurement	Measurement
Measurement	Measurement	Measurement	% Oxygen
Measurement	Measurement	Measurement	% Oxygen
Measurement	Ppm H2S	% Oxygen	Measurement
Measurement	Measurement	Measurement	Measurement
Measurement	% Oxygen	Measurement	Measurement
Measurement	Measurement	Measurement	Measurement
Measurement	Measurement	Measurement	Measurement
Measurement	Ch. 32 off	Ch. 48 off	Measurement

Figure 2-35



# SECTION - 3 INPUT/OUTPUT BOARDS

## 3.1 Main I/O Interface Board #10-0331

The most basic WX64 Controller requires only the I/O Board shown in Figure 3-1 for interfacing to field wiring. The WX64 primary power supply is applied to terminals 1 & 3(+) and 5 & 7(-) of TB4. This may be from 10 – 30 VDC. **WARNING! HIGH VOLTAGES SUCH AS 115 VAC APPLIED TO THESE TERMINALS MAY CAUSE SEVERE DAMAGE!** DC output terminals 2 & 4(+) and 6 & 8(-) on TB4 provide up to 500mA of fused output power for powering remote devices such as lamps, transmitters etc.



This Board includes two RS-485 ports that can be independently configured either *master* or *slave*, one Ethernet port, five Standard SPDT 5A relays, consisting of one dedicated HORN and FAULT relay plus 3 programmable alarm relays, and power supply I/O terminals. The Ethernet port allows the unit to be a ModBusTCP *Master and Slave* and also provides access to the embedded webpage. The failsafe Fault circuit detects firmware and CPU failures along with transmitter failures. JP1 allows the RS-485 ports to be configured for 2- or 4-wire operation. A 40 pin ribbon cable connects the I/O Board to the WX64 CPU and Display nest assembly. Two I<sup>2</sup>C bus connectors allow addition of optional functions such as analog I/O and discrete alarm relays for each channel.

Horizontal jumpers installed in position 1 at JP1 connect the RS-485 port's RX & TX lines, simplifying 2-wire daisy chains by providing additional terminals for incoming and outgoing cables. For example, installing the two COM 1 jumpers connects screw terminals 1 & 5 and terminals 3 & 7 at TB3. RS-485 terminating resistors R5 (COM 1) and R11 (COM 2) are located on the MAIN I/O Board and installed by moving the jumpers at JP2 to position 1. These resistors should not be installed if the port is not at the end of the communication line.

TB1 of the Main I/O Board allows the WX64 to be acknowledged remotely. A low signal at this input will simulate an Alarm Reset event ([see section 2.3.1.2](#)). The '+' input of TB1 is pulled up to +5V. An external circuit or relay can pull the '+' input low (to the '-' input) to activate the Alarm Reset event. The wiring to the external circuitry should be no longer than 10 feet.

An optional Auxiliary Standard Relay *piggyback* Board (part #10-0332) may be added to the I/O Board via ribbon cable J3. This option adds another five SPDT 5A relays that mimic the five standard relays. Auxiliary Standard Relay contacts are available at TB1 on the optional 10-0332 shown in Figure 3-1.

An optional RS-485 Isolated *piggyback* Board (part #10-0368) may be added to the I/O Board via ribbon cable J5. This option adds two additional isolated RS-485 ports for a total of four. These two additional serial ports can also be configured for either Master or Slave. Horizontal jumpers installed in position 1 at JP2 & JP3 (com port 3) and JP5 & JP6 (com port 4) connects the RS-485 port's RX & TX lines, simplifying 2-wire daisy chains by providing additional terminals for incoming and outgoing cables. For

example, installing the two COM 1 jumpers connects screw terminals 1 & 5 and terminals 3 & 7 at TB1. RS-485 terminating resistors are installed by moving the jumpers at JP1 (com port 3) and JP4 (com port 4) to position 1. These resistors should not be installed if the port is not at the end of the communication line.




Figure 3-1  
Main I/O Board

### 3.2 Input / Output Option Boards

Telephone style RJ11 connections (J3 and J4 on all option Boards) are used to add optional 16 channel analog and digital I/O. All option Boards must have 24 VDC applied to TB3 or TB4 which are tied together making daisy chaining the 24 VDC from one option board to another possible. All I/O options except the Programmable Relay Board have LEDs to indicate which channel and alarm they are assigned to. The Programmable Relay is not limited to groups of 16 channels like the other options, so the LEDs are not required. The connected I/O screen in the *Diagnostics Menu* is also useful for displaying and programming the connected I/O Boards.

### 3.2.1 Optional Analog Input Board #10-0334

Many transmitters or sensors have analog output signals, and the 12 bit *Analog Input Board*, shown in Figure 3-2, is available to accept these. TB1 and TB2, with 24 positions each, offer 3 terminals per channel for distributing power and receiving analog inputs. These are **EXC** and **HI / LO** inputs. TB3 and TB4, with only two positions each, are for daisy chaining the power supply from one option board to another. Precision 150 ohm 5 watt resistors (R1 – R16) between each channel's **IN LO** and **IN HI** terminals are termination resistors for 4-20mA inputs.

**EXC** and **IN LO** terminals are bussed together internally. **EXC** terminals are tied directly to TB3 and TB4 +24 VDC and **IN LO** terminals are tied to TB3 and TB4 power supply common. Bussing allows transmitter power to be brought into the system at a single point (TB3 or TB4) and distributed back out at each channel's **EXC / IN LO** terminals to simplify field wiring. Figure 3-2 includes typical wiring to 2 & 3 wire 4-20mA transmitters.




Figure 3-2

### 3.2.2 Optional Discrete Relay Board #10-0345

An optional *Discrete Relay Board*, shown in Figure 3-3, adds 16 5 amp (resistive) form C relays per 16 channel alarm board. Each BOARD may be configured via Diagnostics Menu in the WX64 for ALARM 1, ALARM 2, ALARM 3 or FAULT for channels 1-16, 17-32, 33-48 or 49-64. Each relay has an LED associated with it indicating whether the relay is energized. An illuminated LED indicates energized. Alarm groups, or zones, may be created by connecting adjacent channels together using JP5 as shown. This creates an *OR* function with selected channels, causing *any* alarm included within the zone to actuate *ALL* zoned relays. *Failsafe* operation of 10-0345 discrete relays may be programmed in the *system configuration* menu as described in [section 2.3.3](#). Many WX64 applications utilize the five standard alarm relays ([see section 3.0](#)) and 16 optional programmable relay board, and do not require discrete relays for each of the 64 alarm events (64 A1s, 64 A2s, 64 A3s & 64 Faults). If discrete relays are needed for all 64 alarms, then 16 boards are required. Each 10-0345 is powered with 24 VDC at TB3 and TB4.

TB5 provides an open collector failure detection output. If communication is lost with the CPU board or if the relay board's processor fails, the positive terminal of TB5 is pulled low.



All relays are rated at 5 Amp for 28 VDC and 250 ~VAC **RESISTIVE** loads. **IMPORTANT:** Appropriate diode (DC loads) or MOV (AC loads) snubber devices must be installed with inductive loads to prevent RFI noise spikes. Relay wiring should be kept separate from low-level signal wiring.




Figure 3-3

### 3.2.3 Optional \*Bridge Sensor Input Board #10-0347

An optional 16-channel, 12 bit *Bridge Sensor Input board* allows popular gas detectors to be connected directly to the WX64 without additional signal conditioning or transmitters. Up to eight dual channel 10-0192 modules may be installed in each 16-channel 10-0347. Each 10-0192 channel is equipped with a bridge amplifier and balance potentiometer and an adjustable switching regulator for setting the correct sensor excitation voltage. A three position coarse gain jumper allows setting the gain of the bridge amplifier. Fault supervision circuitry forces the WX64 into a FAULT condition upon sensor failure or removal.

This option may also be configured to accept 4-20mA inputs for mixing bridge sensors and current loops into the same board. Placing any channel's 2 position LEL/4-20mA jumper into 4-20mA position and installing the associated precision 100 ohm socketed resistor allows 4-20mA signals to be applied to its C & A terminals. The 10-0192 sensor modules are not required for channels accepting 4-20mA.

Channels receiving input data from this board should have the *Data From:* menu set for *Analog Input*, as described in [section 2.4.4](#). The board default activates *Cal Mode* described in [section 2.4.4.4](#) needed to *zero* and *span* sensor readings. After performing the one-time only *Initial Setup* as described below, all subsequent calibrations are by the WX64's electronic Cal Mode menus.

\*Catalytic sensors connected directly to the WX64 should be limited to ranges of 0-1000ppm.

### 3.2.4 Bridge Sensor Input Board Initial Setup

Catalytic bead sensors vary widely in power requirements and sensitivity. It is therefore important to configure each channel to match the sensor with which it will operate.

1. Prior to connecting sensors, apply power to the system. Note this board requires 24 VDC power be connected to its TB3 or TB4 terminals 1 & 2 as shown in Figure 3-4. Measure the voltage between each channel's A and R terminals and set the *Voltage Adjust* potentiometers for the correct sensor excitation voltage. This may range from 1.5 volts to 7.5 volts depending upon sensor specifications.



**Sensors may be damaged by accidental over voltage conditions. It is recommended the *Voltage Adjust* potentiometer screws be covered by a dollop of RTV or similar material after completion of this procedure to avoid accidental over voltage conditions.**

2. Remove system power and connect sensor wires to the R-C-A terminals. Reapply system power and confirm correct voltage across each sensor's A & R terminals. Note: If sensor wires are long, it may be necessary to measure the excitation voltage at the sensor end to compensate for  $I^2R$  losses in the wiring.
3. With the minus voltmeter lead on TB3 common, connect the plus lead to the channel's red test point. With zero air on that sensor, adjust its *Balance* potentiometer for .4 volts at the test point.

- Apply 50% LEL combustible span gas to the sensor and allow the test point voltage to stabilize. Two volts = 100% input to the A – D Converter and .4 volts = 0%. Therefore, 1.2 volts = 50%. Place the 3 position *Coarse LEL Gain* jumper into the position which reads between .8 volts and 1.2 volts on the test point with 50% LEL gas on the sensor. Gain settings for each jumper position are as follows: no jumper = 1, LOW = 7, MED = 21, HI = 41. Multiple jumpers have an additive affect upon gain, so the LOW and MED jumpers together provide a gain of 28.

Initial setup is now complete and normally only requires repeating if a sensor is replaced. Final calibration of this channel may now be performed using the WX64's electronic Cal Mode feature described in [section 2.4.4.4](#).




Figure 3-4

### 3.2.5 Optional 4-20mA Analog Output Board #10-0348

An optional 16 bit 4-20mA analog output board, shown in Figure 3-5, may be connected to the I<sup>2</sup>C bus. Each channel's output will transmit 4mA for 0% readings and



20mA for 100% readings. Loop drive capability depends upon the level of the WX64's primary DC power supply. With at least 20 volts DC primary power, they are capable of driving 20mA through a 750 ohm load. Outputs are self-powered, and DC power should not be provided by the receiving device. Note: This board requires nominal 24 VDC power be connected to TB3 or TB4 terminals as shown in Figure 3-5. Since the board has 16 channels, four are required for 64-channel applications.

The analog output board has a failure detection circuit. If the output board's processor fails, or if communication is lost with the CPU board, then the outputs of all channels go to 0mA.




Figure 3-5

### 3.2.6 Optional Programmable Relay Board #10-0350

An optional *Programmable Relay Board*, shown in Figure 3-6, adds 16 programmable 5 amp (resistive) form C relays per 16-channel alarm board. Each relay may be configured via the Alarm Outputs Menu in the WX64 Main Menu for ALARM 1 VOTES, ALARM 2 VOTES, ALARM 3 VOTES, ACKNOWLEDGE, FAILSAFE, ZONES and OVERRIDES. Each relay can be individually programmed for any channel or combination of channels using the zone and override parameters. Many WX64

applications need more than the five standard relays that are provided on the Main I/O Board, but do not need a separate relay contact for each channel. The Programmable Relay Board is a viable cost-effective option. It gives the flexibility of an additional 16 fully programmable relays.

Each 10-0350 is powered with 24 VDC at TB3 and TB4. Each relay has a LED associated with it indicating whether the relay is energized. An illuminated LED indicates energized relays.

TB5 provides an open collector failure detection output. If communication is lost with the CPU board or if the relay board's processor fails, the positive terminal of TB5 is pulled low.



All relays are rated at 5 Amp for 28 VDC and 250 ~VAC **RESISTIVE** loads. **IMPORTANT:** Appropriate diode (DC loads) or MOV (AC loads) snubber devices must be installed with inductive loads to prevent RFI noise spikes. Relay wiring should be kept separate from low-level signal wiring.





Figure 3-6

### 3.2.7 Optional 24 VDC 600 Watt Power Supply

The WX64 Controller may be powered from 10-30 VDC. However, many applications require 24 VDC power for the monitors or transmitters providing inputs to the WX64. A 600 watt AC / DC power supply may be included for these applications (115VAC or 230VAC). When ordered from the factory, it is pre-wired to provide 24 VDC primary


power for the WX64 controller as well as any transmitters or monitors that may be connected by the end user.



**Figure 3-7**  
**600 Watt 24 VDC Power Supply**

### 3.2.8 Optional 24 VDC 150 Watt Power Supply #10-0172

The WX64 Controller may be powered from 10-30 VDC. However, many applications require 24 VDC power for the monitors or transmitters providing inputs to the WX64. A 150 watt AC / DC power supply may be included for these applications (115VAC or 230 VAC selected via slide switch). When ordered from the factory, it is pre-wired to provide 24 VDC primary power for the WX64 controller as well as any transmitters or monitors that may be connected by the end user.




150 Watt 24 VDC Power Supply Option #10-0172

Figure 3-8

# SECTION - 4 DIAGNOSTICS

A *System Diagnostic Mode* shown in Figure 2-5 - Figure 2-7 may be entered during normal operation from the MAIN menu. The entry menu, shown below, offers useful routines for testing front panel LEDs, relays, serial ports and analog I/O. It is exited


manually by pressing  and automatically if no keys are pressed for 5 minutes. The unit will reboot when diagnostics is exited. It is very important to understand that

**CHANNEL INPUT DATA IS NOT PROCESSED DURING THE DIAGNOSTICS MODE.** It is possible to miss important input values while utilizing this mode and appropriate safeguards should be in place. However, the Diagnostics Mode can prove invaluable when testing I/O since relays and analog outputs may be stimulated without driving inputs to precise levels.



## 4.1 Standard Relays


**STANDARD RELAY** allows manual actuation of the Standard Relays while in the


Diagnostic mode. Highlight the relay to be actuated and press  LEDs on the Main I/O board confirm relay actuation.

Standard Relay	
Standard Relay 1	Off
Standard Relay 2	Off
Standard Relay 3	Off
Fault Relay	Off
Horn Relay	Off

Figure 4-1

## 4.2 Discrete Relays


**DISCRETE RELAYS** allows manual actuation of the connected Discrete Relays while in the Diagnostic mode. Highlight the channel group to be actuated and press .

Then select the alarm group and press . These steps bring you to the screen on the right in Figure 4-2 and allow the actuation of each relay in the group to be activated individually. LEDs on the Discrete Relay board confirm relay actuation.

Discrete Relay			Discrete Relay Ch.01-16			Alarm 1		
Discrete Relay Ch.01-16	~	→	Alarm 1	~	→	Ch.01 Alarm 1	Of f	
Discrete Relay Ch.17-32	~		Alarm 2	~		Ch.02 Alarm 1	Of f	
Discrete Relay Ch.33-48	~		Alarm 3	~		Ch.03 Alarm 1	Of f	
Discrete Relay Ch.49-64	~		Fault	~		Ch.04 Alarm 1	Of f	
						Ch.05 Alarm 1	Of f	
						" " "	"	
						Ch.16 Alarm 1	Of f	

Figure 4-2

## 4.3 Programmable Relays

**PROGRAMMABLE RELAY** allows manual actuation of the Programmable Relays while in the Diagnostic mode. Highlight the relay to be actuated and press  LEDs on the Programmable Relay board confirm relay actuation.

Programmable		
Programmable Rly.01	Of f	
Programmable Rly.02	Of f	
Programmable Rly.03	Of f	
Programmable Rly.04	Of f	
Programmable Rly.05	Of f	
" " "	"	
Programmable Rly.16	Of f	

Figure 4-3

## 4.4 Analog Inputs

By selecting a channel group you can **VIEW INPUTS** or **CALIBRATE BOARD**.




Figure 4-4

### 4.4.1 View Inputs

The channel inputs are displayed as raw counts and can be useful for troubleshooting. These counts have no calibration applied to them so the user can see a particular channel's Analog to Digital counts.


### 4.4.2 Calibrate Board


Initial calibrating of each analog input channel is done at the factory by selecting each channel, one at a time, and applying 20mA. The analog input board self-adjusts its output and stores this value in non-volatile memory.

## 4.5 Analog Outputs

If the WX64 is equipped with an analog output option board, the output can be manually stimulated by selecting the channel group then the channel to be ramped up.



Pressing the  increases the output value in 4mA increments from 0mA to 20mA.

The image shows two screenshots of a menu. The left screenshot shows a list of channel groups: "Analog Output Ch. 01- 16 ~", "Analog Output Ch. 17 - 32 ~", "Analog Output Ch. 33- 48 ~", and "Analog Output Ch. 49- 64 ~". The first option is highlighted in blue. An arrow points from this option to the right screenshot. The right screenshot shows a list of individual channels: "Analog Out 1 8 mA", "Analog Out 2 4 mA", "Analog Out 3 12 mA", "Analog Out 4 20 mA", "Analog Out 5 16 mA", a separator line with three quotes, and "Analog Out 16 0 mA". The first option is highlighted in blue.

Analog Output	
Analog Output Ch. 01- 16 ~	
Analog Output Ch. 17 - 32 ~	
Analog Output Ch. 33- 48 ~	
Analog Output Ch. 49- 64 ~	

Analog Output Ch. 01- 16	
Analog Out 1	8 mA
Analog Out 2	4 mA
Analog Out 3	12 mA
Analog Out 4	20 mA
Analog Out 5	16 mA
" " "	"
Analog Out 16	0 mA

Figure 4-5

## 4.6 Piezo

Selecting **PIEZO** pulses the controller's local piezo buzzer.





Figure 4-6



## 4.7 LEDs

Selecting LEDs from the diagnostics menu causes the six LEDs on the front panel to blink without affecting their corresponding relays.



**Figure 4-7**

## 4.8 Serial Ports

Testing the controller's 2 standard and 2 optional communication ports is made easy by connecting the ports together as shown in Figure 4-8 and selecting **SERIAL PORTS** in the diagnostic menu. The controller does a self-diagnostic by polling one communication port with the other to ensure correct operation. It gives a **SUCCESS** or **FAILURE** report.





Figure 4-8

## 4.9 I/O Board Configuration

The board configuration screen shows all connected I/O options. This is also the menu where the user must go if s/he wants to change the configuration or channel group of an option board. To change the configuration of an option board, first go to the I/O Board configuration screen. All the connected I/O boards are displayed. Second, remove the PGM jumper J2 on the option board you want to configure. A box will be

displayed as show below in Figure 4-9. Use  /  to select the parameter to be

changed and press the  to toggle trough the options. Third, replace the PGM jumper J2, once the correct configuration is selected. The box will disappear once the jumper is reinstalled. These three steps can be repeated for as many options as necessary, but only one PGM jumper J2 can be removed at a time.




Figure 4-9



# SECTION - 5 ModBus

The WX64 is equipped with two standard RS-485 ports that can be independently configured as ModBus *master* or *slave*, an optional RS-485 Isolated *piggyback* Board (part # 10-0368) may be added to the I/O Board via ribbon cable J5. This option adds two additional isolated RS-485 ports for a total of four. These two additional serial ports can also be configured for either Master or Slave. Section 5.0 defines register locations of data available via the WX64 slave port.

## 5.1 ModBus TCP

In addition to the RS-485 ports, the WX64 supports both *master* and *slave* ModBusTCP. ModBusTCP is always enabled through the Ethernet port. [See section 2.5](#) for ModBus configuration options. The ModBusTCP slave is always active on port 502. The unit can be polled by its IP Address or hostname. When ModBusTCP slave is used, the slave ID field of the message is ignored. Channels can be configured to poll using the WX64's ModBusTCP master interface. Devices are polled by IP Address, not hostname.

## 5.2 ModBus Slave Writes

The ModBus slave ports allow function code 5 (write coil), as well as function codes 6 and 16 (write holding registers). These function codes can be used to write configuration parameters to the WX64. By default, all ModBus writes are disabled except the unlock parameter 40099. The ModBus lock code can be written to register 40099 to enable writes to other registers. The unit will be unlocked for 10 minutes after the last write occurs. After the 10 minute timeout, the unit will automatically save any parameters that have been written. All written parameters can be saved manually by writing a value of 1 to coil 95 or register 40095.

Writing parameters that span multiple registers (such as 32bit floating points) requires function code 16. All of the registers must be written at once.

## 5.3 ModBus Slave Register Location

The following tables describe the WX64's ModBus slave database. Any portion of this data may be read by a ModBus master device such as a PC, PLC or DCS. Since the ModBus port is RS-485, many WX64s may be multi-dropped onto the same cable.

### 5.3.1 Coils

All coils are duplicated in the holding register table. These values can be read or written using either the coil register or the holding register.

Actions							
Alarm Reset	N/A	1	1	N/A	1	5	Write 1 to simulate pressing the alarm reset button
Save Config	N/A	95	95	N/A	1	5	Saves configuration now
Config Changed	N/A	96	96	N/A	1	5	This register is set to 1 when a configuration parameter has changed. The user can clear it by writing 0.

### 5.3.2 Discrete Inputs

All discrete inputs are duplicated in the input register table. These values can be read using either discrete register or the holding register.

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Lock Status	N/A	12005	12005	N/A	2	N/A	Indicates the lock state for ModBus writes. Locked = 1 Unlocked = 0
Standard Relay 1 State	N/A	12020	12020	N/A	2	N/A	Off = 0, On = 1, doesn't take into account failsafe
Standard Relay 2 State	N/A	12021	12021	N/A	2	N/A	Off = 0, On = 1, doesn't take into account failsafe
Standard Relay 3 State	N/A	12022	12022	N/A	2	N/A	Off = 0, On = 1, doesn't take into account failsafe

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Fault Relay State	N/A	12023	12023	N/A	2	N/A	Off = 0, On = 1, doesn't take into account failsafe
Horn Relay State	N/A	12024	12024	N/A	2	N/A	Off = 0, On = 1, doesn't take into account failsafe
Warmup	N/A	12025	12025	N/A	2	N/A	Not in warmup = 0 In warmup = 1
Standard Relay 1 Flashing	N/A	12026	12020	N/A	4	N/A	False = 0, True = 1. Indicates whether standard relay 1 has been acknowledged.
Standard Relay 2 Flashing	N/A	12027	12027	N/A	4	N/A	False = 0, True = 1. Indicates whether standard relay 2 has been acknowledged.
Standard Relay 3 Flashing	N/A	12028	12028	N/A	4	N/A	False = 0, True = 1. Indicates whether standard relay 3 has been acknowledged.
Fault Relay Flashing	N/A	12029	12029	N/A	4	N/A	False = 0, True = 1. Indicates whether the fault has been acknowledged.
Horn Relay Flashing	N/A	12034	12034	N/A	4	N/A	False = 0, True = 1. Indicates whether the horn relay has been acknowledged.

## Channel Data

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Alarm 1 Status	1-64	13449	13512	1	2	N/A	Off = 0, On = 1
Alarm 1 Flashing	1-64	13513	13576	1	2	N/A	Off = 0, On = 1
Alarm 2 Status	1-64	13577	13640	1	2	N/A	Off = 0, On = 1
Alarm 2 Flashing	1-64	13641	13704	1	2	N/A	Off = 0, On = 1
Alarm 3 Status	1-64	13705	13768	1	2	N/A	Off = 0, On = 1
Alarm 3 Flashing	1-64	13769	13832	1	2	N/A	Off = 0, On = 1
Fault Status	1-64	13833	13896	1	2	N/A	Off = 0, On = 1
Comm Error	1-64	13897	13960	1	2	N/A	Off = 0, On = 1
Config Error	1-64	13961	14024	1	2	N/A	Off = 0, On = 1
IO Error	1-64	14025	14088	1	2	N/A	Off = 0, On = 1
Cal Flag	1-64	14089	14152	1	2	N/A	Off = 0, On = 1
Marker Detected	1-64	14153	14216	1	2	N/A	Off = 0, On = 1
Linearizing	1-64	14217	14280	1	2	N/A	Set if the channel's linearize map is non default. Off = 0, On = 1
Error Flashing	1-64	14281	14344	1	2	N/A	Unacknowledged error. Off = 0, On = 1



### 5.3.3 Input Registers

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Product ID	N/A	32001	32001	N/A	4	N/A	Reads value 72
Version	N/A	32002	32002	N/A	4	N/A	Reads version * 100
Custom Feature	N/A	32003	32003	N/A	4	N/A	N/A
Customer ID	N/A	32004	32004	N/A	4	N/A	N/A
Lock Status	N/A	32005	32005	N/A	4	N/A	Indicates the lock state for ModBus writes. Locked = 1 Unlocked = 0
Boot Date, Year	N/A	32006	32006	N/A	4	N/A	System boot timestamp 0000 - 9999
Boot Date, Mon	N/A	32007	32007	N/A	4	N/A	System boot timestamp 0 – 12
Boot Date, Day	N/A	32008	32008	N/A	4	N/A	System boot timestamp 0 – 31
Boot Time, Hour	N/A	32009	32009	N/A	4	N/A	System boot timestamp 0 – 23
Boot Time, Min	N/A	32010	32010	N/A	4	N/A	System boot timestamp 0 – 59
Boot Time, Sec	N/A	32011	32011	N/A	4	N/A	System boot timestamp 0 – 59
Standard Relay 1 State	N/A	32020	32020	N/A	4	N/A	Off = 0, On = 1, doesn't take into account failsafe
Standard Relay 2 State	N/A	32021	32021	N/A	4	N/A	Off = 0, On = 1, doesn't take into account failsafe
Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Standard Relay 3 State	N/A	32022	32022	N/A	4	N/A	Off = 0, On = 1, doesn't take into account failsafe

Fault Relay State	N/A	32023	32023	N/A	4	N/A	Off = 0, On = 1, doesn't take into account failsafe
Horn Relay State	N/A	32024	32024	N/A	4	N/A	Off = 0, On = 1, doesn't take into account failsafe
Warmup	N/A	32025	32025	N/A	4	N/A	Not in warmup = 0 In warmup = 1
Standard Relay 1 Flashing	N/A	32026	32020	N/A	4	N/A	False = 0, True = 1. Indicates whether standard relay 1 has been acknowledged.
Standard Relay 2 Flashing	N/A	32027	32027	N/A	4	N/A	False = 0, True = 1. Indicates whether standard relay 2 has been acknowledged.
Standard Relay 3 Flashing	N/A	32028	32028	N/A	4	N/A	False = 0, True = 1. Indicates whether standard relay 3 has been acknowledged.
Fault Relay Flashing	N/A	32029	32029	N/A	4	N/A	False = 0, True = 1. Indicates whether the fault has been acknowledged.
Horn Relay Flashing	N/A	32034	32034	N/A	4	N/A	False = 0, True = 1. Indicates whether the horn relay has been acknowledged.

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Active Port for COM1	N/A	32030	32030	N/A	4	N/A	When a redundant port is enabled, this value indicates which port is in use. (0) or the port number of the redundant port (1-3). (PortNumber – 1)
Active Port for COM2	N/A	32031	32031	N/A	4	N/A	See active port for COM1. (1) or the port number of the redundant port (0,2,3). (PortNumber – 1)
Active Port for COM3	N/A	32032	32032	N/A	4	N/A	See active port for COM1. (2) or the port number of the redundant port (0,1,3). (PortNumber – 1)
Active Port for COM4	N/A	32033	32033	N/A	4	N/A	See active port for COM1. (3) or the port number of the redundant port (0-2). (PortNumber – 1)

## Channel Data

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Analog Output	1-64	31001	31064	1	4	N/A	16bit integer value tracking analog output. Uses a range of 800 – 4000 to represent 4-20mA.
Channel Value	1-64	33001	33064	1	4	N/A	16bit representation of float w/ $\pm 5\%$ over/under range. * see formula
Channel Value	1-64	33065	33192	2	4	N/A	32bit IEEE Floating point
Channel Value	1-64	33193	33384	3	4	N/A	Character string representation of value. 2 ASCII characters per register
Alarm 1 Status	1-64	33449	33512	1	4	N/A	Off = 0, On = 1
Alarm 1 Flashing	1-64	33513	33576	1	4	N/A	Off = 0, On = 1
Alarm 2 Status	1-64	33577	33640	1	4	N/A	Off = 0, On = 1
Alarm 2 Flashing	1-64	33641	33704	1	4	N/A	Off = 0, On = 1
Alarm 3 Status	1-64	33705	33768	1	4	N/A	Off = 0, On = 1
Alarm 3 Flashing	1-64	33769	33832	1	4	N/A	Off = 0, On = 1
Fault Status	1-64	33833	33896	1	4	N/A	Off = 0, On = 1
Comm Error	1-64	33897	33960	1	4	N/A	Off = 0, On = 1
Config Error	1-64	33961	34024	1	4	N/A	Off = 0, On = 1
IO Error	1-64	34025	34088	1	4	N/A	Off = 0, On = 1

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Cal Flag	1-64	34089	34152	1	4	N/A	Off = 0, On = 1
Marker Detected	1-64	34153	34216	1	2	N/A	Off = 0, On = 1
Linearizing	1-64	34217	34280	1	2	N/A	Set if the channel's linearize map is non default. Off = 0, On = 1
Error Flashing	1-64	34281	34344	1	2	N/A	Unacknowledged error. Off = 0, On = 1
Sensor Life	1-64	34401	34464	1	4	N/A	-2 = Disabled, -1 = Cal Required, 0 – 100 = Sensor life

\* 16bit representation of float w/ ±5% over/under range is calculated as follows:

$$\text{DisplayValue} = \text{ModBusValue} * \frac{(\text{SpanValue} - \text{ZeroValue}) * 1.1}{32767} + \text{ZeroValue} - (\text{SpanValue} - \text{ZeroValue}) * 0.5$$

### 5.3.4 Holding Registers

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Alarm Reset	N/A	40001	40001	N/A	3	6, 16	Simulates the alarm reset button. Write a value of 1 to activate.
System Name	N/A	40010	40017	N/A	3	6, 16	Character string, 2 characters per register
Date, Year	N/A	40020	40020	N/A	3	6, 16	0000 - 9999
Date, Mon	N/A	40021	40021	N/A	3	6, 16	0 – 12
Date, Day	N/A	40022	40022	N/A	3	6, 16	0 – 31
Time, Hour	N/A	40023	40023	N/A	3	6, 16	0 – 23
Time, Min	N/A	40024	40024	N/A	3	6, 16	0 – 59
Time, Sec	N/A	40025	40025	N/A	3	6, 16	0 – 59

Warmup Time	N/A	40027	40027	N/A	3	6, 16	Time in minutes. 0 – 5
Cal Purge Time	N/A	40028	40028	N/A	3	6, 16	Time in minutes. 0 – 5
Block Negative	N/A	40029	40029	N/A	3	6, 16	<b>No</b> = 0, <b>Yes</b> = 1

### Zone Names

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Zone 1 Name	N/A	40030	40037	N/A	3	6, 16	Character string, 2 characters per register
Zone 2 Name	N/A	40038	40045	N/A	3	6, 16	Character string, 2 characters per register
Zone 3 Name	N/A	40046	40053	N/A	3	6, 16	Character string, 2 characters per register
Zone 4 Name	N/A	40054	40062	N/A	3	6, 16	Character string, 2 characters per register
Zone 5 Name	N/A	40062	40069	N/A	3	6, 16	Character string, 2 characters per register
Zone 6 Name	N/A	40070	40077	N/A	3	6, 16	Character string, 2 characters per register
Zone 7 Name	N/A	40078	40085	N/A	3	6, 16	Character string, 2 characters per register
Zone 8 Name	N/A	40086	40093	N/A	3	6, 16	Character string, 2 characters per register

## Actions

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Save Config	N/A	40095	40095	N/A	3	6	Saves configuration now
Config Changed	N/A	40096	40096	N/A	3	6	This register is set to 1 when a configuration parameter has changed. The user can clear it by writing 0.
Security Unlock	N/A	40099	40099	N/A	3	6	This register must be written with the ModBus unlock code before any parameter can be written using function codes 6 or 16. 0000 – 9999, <b>1234</b>

### 5.3.5 Standard Relay 1

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
A1 Votes	N/A	40100	40100	N/A	3	6, 16	Alarm 1 channels required. 0 - 64
A2 Votes	N/A	40101	40101	N/A	3	6, 16	Alarm 2 channels required. 0 – 64
A3 Votes	N/A	40102	40102	N/A	3	6, 16	Alarm 3 channels required. 0 - 64
Acknowledge	N/A	40103	40103	N/A	3	6, 16	Relay is acknowledgeable. <b>No</b> = 0, <b>Yes</b> = 1
Failsafe	N/A	40104	40104	N/A	3	6, 16	Relay is failsafe. <b>No</b> = 0, <b>Yes</b> = 1
Zone 1 Enable	N/A	40105	40105	N/A	3	6, 16	Use zone 1 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Zone 2 Enable	N/A	40106	40106	N/A	3	6, 16	Use zone 2 channels for voting. No = 0, <b>Yes</b> = 1
Zone 3 Enable	N/A	40107	40107	N/A	3	6, 16	Use zone 3 channels for voting. No = 0, <b>Yes</b> = 1
Zone 4 Enable	N/A	40108	40108	N/A	3	6, 16	Use zone 4 channels for voting. No = 0, <b>Yes</b> = 1
Zone 5 Enable	N/A	40109	40109	N/A	3	6, 16	Use zone 5 channels for voting. No = 0, <b>Yes</b> = 1
Zone 6 Enable	N/A	40110	40110	N/A	3	6, 16	Use zone 6 channels for voting. No = 0, <b>Yes</b> = 1
Zone 7 Enable	N/A	40111	40111	N/A	3	6, 16	Use zone 7 channels for voting. No = 0, <b>Yes</b> = 1
Zone 8 Enable	N/A	40112	40112	N/A	3	6, 16	Use zone 8 channels for voting. No = 0, <b>Yes</b> = 1
Override 1 Channel	N/A	40113	40113	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 1 Alarm	N/A	40114	40114	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2



Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Override 2 Channel	N/A	40115	40115	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 2 Alarm	N/A	40116	40116	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, <b>Alarm 2</b> = 1, <b>Alarm 3</b> = 2
Override 3 Channel	N/A	40117	40117	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 3 Alarm	N/A	40118	40118	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, <b>Alarm 2</b> = 1, <b>Alarm 3</b> = 2
Override 4 Channel	N/A	40119	40119	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 4 Alarm	N/A	40120	40120	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, <b>Alarm 2</b> = 1, <b>Alarm 3</b> = 2
Override 5 Channel	N/A	40121	40121	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Override 5 Alarm	N/A	40122	40122	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, <b>Alarm 2</b> = 1, <b>Alarm 3</b> = 2

Override 6 Channel	N/A	40123	40123	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 6 Alarm	N/A	40124	40124	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2
Override 7 Channel	N/A	40125	40125	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 7 Alarm	N/A	40126	40126	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2
Override 8 Channel	N/A	40127	40127	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 8 Alarm	N/A	40128	40128	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2

### 5.3.6 Standard Relay 2

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
A1 Votes	N/A	40140	40140	N/A	3	6, 16	Alarm 1 channels required. 0 - 64
A2 Votes	N/A	40141	40141	N/A	3	6, 16	Alarm 2 channels required. 0 - 64
A3 Votes	N/A	40142	40142	N/A	3	6, 16	Alarm 3 channels required. 0 - 64
Acknowledge	N/A	40143	40143	N/A	3	6, 16	Relay is acknowledgeable. <b>No</b> = 0, <b>Yes</b> = 1
Failsafe	N/A	40144	40144	N/A	3	6, 16	Relay is failsafe. <b>No</b> = 0, <b>Yes</b> = 1

Zone 1 Enable	N/A	40145	40145	N/A	3	6, 16	Use zone 1 channels for voting. No = 0, <b>Yes</b> = 1
Zone 2 Enable	N/A	40146	40146	N/A	3	6, 16	Use zone 2 channels for voting. No = 0, <b>Yes</b> = 1
Zone 3 Enable	N/A	40147	40147	N/A	3	6, 16	Use zone 3 channels for voting. No = 0, <b>Yes</b> = 1
Zone 4 Enable	N/A	40148	40148	N/A	3	6, 16	Use zone 4 channels for voting. No = 0, <b>Yes</b> = 1
Zone 5 Enable	N/A	40149	40149	N/A	3	6, 16	Use zone 5 channels for voting. No = 0, <b>Yes</b> = 1
Zone 6 Enable	N/A	40150	40150	N/A	3	6, 16	Use zone 6 channels for voting. No = 0, <b>Yes</b> = 1
Zone 7 Enable	N/A	40151	40151	N/A	3	6, 16	Use zone 7 channels for voting. No = 0, <b>Yes</b> = 1
Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Zone 8 Enable	N/A	40152	40152	N/A	3	6, 16	Use zone 8 channels for voting. No = 0, <b>Yes</b> = 1
Override 1 Channel	N/A	40153	40153	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 1 Alarm	N/A	40154	40154	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, <b>Alarm 2</b> = 1, <b>Alarm 3</b> = 2

Override 2 Channel	N/A	40155	40155	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 2 Alarm	N/A	40156	40156	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> <b>Alarm 2 = 1,</b> <b>Alarm 3 = 2</b>
Override 3 Channel	N/A	40157	40157	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 3 Alarm	N/A	40158	40158	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> <b>Alarm 2 = 1,</b> <b>Alarm 3 = 2</b>
Override 4 Channel	N/A	40159	40159	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Override 4 Alarm	N/A	40160	40160	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> <b>Alarm 2 = 1,</b> <b>Alarm 3 = 2</b>
Override 5 Channel	N/A	40161	40161	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 5 Alarm	N/A	40162	40162	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> <b>Alarm 2 = 1,</b> <b>Alarm 3 = 2</b>

Override 6 Channel	N/A	40163	40163	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 6 Alarm	N/A	40164	40164	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2
Override 7 Channel	N/A	40165	40165	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 7 Alarm	N/A	40166	40166	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Override 8 Channel	N/A	40167	40167	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 8 Alarm	N/A	40168	40168	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2

### 5.3.7 Standard Relay 3

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
A1 Votes	N/A	40180	40180	N/A	3	6, 16	Alarm 1 channels required. 0 - 64
A2 Votes	N/A	40181	40181	N/A	3	6, 16	Alarm 2 channels required. 0 - 64
A3 Votes	N/A	40182	40182	N/A	3	6, 16	Alarm 3 channels required. 0 - 64
Acknowledge	N/A	40183	40183	N/A	3	6, 16	Relay is acknowledgeable. <b>No</b> = 0, <b>Yes</b> = 1

Failsafe	N/A	40184	40184	N/A	3	6, 16	Relay is failsafe. <b>No</b> = 0, <b>Yes</b> = 1
Zone 1 Enable	N/A	40185	40185	N/A	3	6, 16	Use zone 1 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 2 Enable	N/A	40186	40186	N/A	3	6, 16	Use zone 2 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 3 Enable	N/A	40187	40187	N/A	3	6, 16	Use zone 3 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Zone 4 Enable	N/A	40188	40188	N/A	3	6, 16	Use zone 4 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 5 Enable	N/A	40189	40189	N/A	3	6, 16	Use zone 5 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 6 Enable	N/A	40190	40190	N/A	3	6, 16	Use zone 6 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 7 Enable	N/A	40191	40191	N/A	3	6, 16	Use zone 7 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 8 Enable	N/A	40192	40192	N/A	3	6, 16	Use zone 8 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Override 1 Channel	N/A	40193	40193	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 1 Alarm	N/A	40194	40194	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, <b>Alarm 2</b> = 1, <b>Alarm 3</b> = 2

Override 2 Channel	N/A	40195	40195	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 2 Alarm	N/A	40196	40196	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> <b>Alarm 2 = 1,</b> <b>Alarm 3 = 2</b>
Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Override 3 Channel	N/A	40197	40197	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 3 Alarm	N/A	40198	40198	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> <b>Alarm 2 = 1,</b> <b>Alarm 3 = 2</b>
Override 4 Channel	N/A	40199	40199	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 4 Alarm	N/A	40200	40200	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> <b>Alarm 2 = 1,</b> <b>Alarm 3 = 2</b>
Override 5 Channel	N/A	40201	40201	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 5 Alarm	N/A	40202	40202	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> <b>Alarm 2 = 1,</b> <b>Alarm 3 = 2</b>
Override 6 Channel	N/A	40203	40203	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64

Override 6 Alarm	N/A	40204	40204	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> Alarm 2 = 1, Alarm 3 = 2
Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Override 7 Channel	N/A	40205	40205	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 7 Alarm	N/A	40206	40206	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> Alarm 2 = 1, Alarm 3 = 2
Override 8 Channel	N/A	40207	40207	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 8 Alarm	N/A	40208	40208	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> Alarm 2 = 1, Alarm 3 = 2

### 5.3.8 Discrete Relays

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
A1 Failsafe	N/A	40220	40220	N/A	3	6, 16	Makes discrete relays boards that use alarm 1 failsafe. <b>No</b> = 0, <b>Yes</b> = 1
A2 Failsafe	N/A	40221	40221	N/A	3	6, 16	Makes discrete relays boards that use alarm 2 failsafe. <b>No</b> = 0, <b>Yes</b> = 1
A3 Failsafe	N/A	40222	40222	N/A	3	6, 16	Makes discrete relays boards that use alarm 3 failsafe. <b>No</b> = 0, <b>Yes</b> = 1



### 5.3.9 Horn/Piezo

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Alarm 1 Mode	N/A	40230	40230	N/A	3	6, 16	Off = 0, On = 1, <b>Beep = 2</b>
Alarm 2 Mode	N/A	40231	40231	N/A	3	6, 16	Off = 0, <b>On = 1</b> , Beep = 2
Alarm 3 Mode	N/A	40232	40232	N/A	3	6, 16	Off = 0, <b>On = 1</b> , Beep = 2
Acknowledge	N/A	40233	40233	N/A	3	6, 16	Off = 0, <b>On = 1</b>
Failsafe	N/A	40234	40234	N/A	3	6, 16	<b>No = 0</b> , Yes = 1
Piezo Alarm	N/A	40235	40235	N/A	3	6, 16	<b>No = 0</b> , Yes = 1

### 5.3.10 Channel Configuration

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Tag	1-64	40401	40912	8	3	16	2 characters per register
Eng. Units	1-64	40913	41104	3	3	16	2 characters per register
Zero Value	1-64	41297	41424	2	3	16	Integer and divisor
Zero Value	1-64	41425	41552	2	3	16	32bit IEEE Float
Span Value	1-64	41553	41680	2	3	16	Integer and divisor
Span Value	1-64	41681	41808	2	3	16	32bit IEEE Float

## Alarm 1

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Setpoint	1-64	41809	41936	2	3	16	Integer and divisor
Setpoint	1-64	41937	42064	2	3	16	32bit IEEE Float
Latching	1-64	42065	42128	1	3	6, 16	<b>No</b> = 0, <b>Yes</b> = 1
Trip	1-64	42129	42192	1	3	6, 16	Low = 0, <b>High</b> = 1
On Delay	1-64	42193	42256	1	3	6, 16	Time in seconds. 0 – 10
Off Delay	1-64	42257	42320	1	3	6, 16	Time in minutes. 0 - 120
Horn Drive	1-64	42321	42448	1	3	6, 16	No = 0, <b>Yes</b> = 1

## Alarm 2

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Setpoint	1-64	42449	42576	2	3	16	Integer and divisor
Setpoint	1-64	42577	42704	2	3	16	32bit IEEE Float
Latching	1-64	42705	42768	1	3	6, 16	<b>No</b> = 0, <b>Yes</b> = 1
Trip	1-64	42769	42832	1	3	6, 16	Low = 0, <b>High</b> = 1
On Delay	1-64	42833	42896	1	3	6, 16	Time in seconds. 0 – 10
Off Delay	1-64	42897	42960	1	3	6, 16	Time in minutes. 0 - 120
Horn Drive	1-64	42961	43024	1	3	6, 16	No = 0, <b>Yes</b> = 1
Color	1-64	43025	43088	1	3	6, 16	Alarm color displayed on the unit <b>Red</b> = 0, Blue = 1, Orange = 2

### Alarm 3

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Setpoint	1-64	43089	43216	2	3	16	Integer and divisor
Setpoint	1-64	43217	43344	2	3	16	32bit IEEE Float
Latching	1-64	43345	43408	1	3	6, 16	<b>No</b> = 0, <b>Yes</b> = 1
Trip	1-64	43409	43472	1	3	6, 16	Low = 0, <b>High</b> = 1
On Delay	1-64	43473	43536	1	3	6, 16	Time in seconds. 0 – 10
Off Delay	1-64	43537	43600	1	3	6, 16	Time in minutes. 0 - 120
Horn Drive	1-64	43601	43664	1	3	6, 16	No = 0, <b>Yes</b> = 1
Color	1-64	43665	43728	1	3	6, 16	Alarm color displayed on the unit <b>Red</b> = 0, <b>Blue</b> = 1, <b>Orange</b> = 2
Enable	1-64	43729	43792	1	3	6, 16	<b>No</b> = 0, <b>Yes</b> = 1

### Fault

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Setpoint	1-64	43793	43920	2	3	16	Integer and divisor
Setpoint	1-64	43921	44048	2	3	16	32bit IEEE Float

## Data From

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Source	1-64	44369	44432	1	3	6, 16	<b>Analog In</b> = 0, ModBus 16bit = 1, Signed ModBus 16bit = 2, ModBus 32bit = 3, Wireless Monitor = 4, Digital In = 5
Min Raw	1-64	44433	44496	1	3	6, 16	Integer
Max Raw	1-64	44497	44560	1	3	6, 16	Integer
Remote ID	1-64	44561	44624	1	3	6, 16	0 – 247
Interface	1-64	44625	44688	1	3	6, 16	<b>COM1</b> = 0 COM2 = 1 COM3 = 2 COM4 = 3 TCP/IP = 4
Filter Count	1-64	44689	44752	1	3	6,16	1 – 40
Local Cal	1-64	44753	44816	1	3	6,16	No = 0, Yes = 1, <b>Board Default</b> = 2
Byte Order	1-64	44881	44944	1	3	6,16	ABCD = 0 CDAB = 1 <b>BADC</b> = 2 DCBA = 3
Alias	1-64	44945	45072	2	3	16	ModBus alias. 0 – 65535
IP Address	1-64	45073	45200	2	3	16	Target address for ModBusTCP
TCP/IP Port	1-64	45201	45328	1	3	6, 16	TCP/IP port for ModBusTCP. 0 - 65535

## Linearize Map

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Point 1	1-64	45329	45584	4	3	16	2x 32bit IEEE Floats, Input and Output
Point 2	1-64	45585	45840	4	3	16	2x 32bit IEEE Floats, Input and Output
Point 3	1-64	45841	46096	4	3	16	2x 32bit IEEE Floats, Input and Output
Point 4	1-64	46097	46352	4	3	16	2x 32bit IEEE Floats, Input and Output
Point 5	1-64	46353	46608	4	3	16	2x 32bit IEEE Floats, Input and Output
Point 6	1-64	46609	46864	4	3	16	2x 32bit IEEE Floats, Input and Output
Point 7	1-64	46865	47120	4	3	16	2x 32bit IEEE Floats, Input and Output
Point 8	1-64	47121	47376	4	3	16	2x 32bit IEEE Floats, Input and Output
Point 9	1-64	47377	47632	4	3	16	2x 32bit IEEE Floats, Input and Output

## Configure

Type	Channel	First	Last	Block Size	Read FC	Write FC	Notes
Decimal Points	1-64	47633	47696	1	3	6, 16	<b>0</b> = 0, <b>1</b> = 1, <b>2</b> = 2, <b>3</b> = 3,
Channel Enable	1-64	47697	47760	1	3	6, 16	<b>No</b> = 0, <b>Yes</b> = 1
Zone	1-64	47761	47824	1	3	6, 16	<b>Zone 1</b> = 0, <b>Zone 2</b> = 1, <b>Zone 3</b> = 2, <b>Zone 4</b> = 3, <b>Zone 5</b> = 4, <b>Zone 6</b> = 5, <b>Zone 7</b> = 6, <b>Zone 8</b> = 7,
Deadband %	1-64	47825	47952	2	3	16	32bit IEEE Float (0.0 – 5.0)

### 5.3.11 Programmable Relays

The programmable relay option allows 16 relays to be configured. The configuration parameters are the same for all 16 relays. The following table shows the base address of each programmable relay.

Programmable Relay Number	Base ModBus Address
<b>Relay 1</b>	<b>49000</b>
<b>Relay 2</b>	<b>49040</b>
<b>Relay 3</b>	<b>49080</b>
<b>Relay 4</b>	<b>49120</b>
<b>Relay 5</b>	<b>49160</b>
<b>Relay 6</b>	<b>49200</b>
<b>Relay 7</b>	<b>49240</b>
<b>Relay 8</b>	<b>49280</b>
<b>Relay 9</b>	<b>49320</b>
<b>Relay 10</b>	<b>49360</b>
<b>Relay 11</b>	<b>49400</b>
<b>Relay 12</b>	<b>49440</b>
<b>Relay 13</b>	<b>49480</b>
<b>Relay 14</b>	<b>49520</b>
<b>Relay 15</b>	<b>49560</b>
<b>Relay 16</b>	<b>49600</b>

The register for each relay parameter is determined by adding the offset to that relay's base address.

Type	Channel	Address Offset	Block Size	Read FC	Write FC	Notes
A1 Votes	N/A	0	N/A	3	6, 16	Alarm 1 channels required. 0 - 64
A2 Votes	N/A	1	N/A	3	6, 16	Alarm 2 channels required. 0 – 64
A3 Votes	N/A	2	N/A	3	6, 16	Alarm 3 channels required. 0 - 64
Acknowledge	N/A	3	N/A	3	6, 16	Relay is acknowledgeable. <b>No</b> = 0, <b>Yes</b> = 1
Failsafe	N/A	4	N/A	3	6, 16	Relay is failsafe. <b>No</b> = 0, <b>Yes</b> = 1
Zone 1 Enable	N/A	5	N/A	3	6, 16	Use zone 1 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 2 Enable	N/A	6	N/A	3	6, 16	Use zone 2 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 3 Enable	N/A	7	N/A	3	6, 16	Use zone 3 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 4 Enable	N/A	8	N/A	3	6, 16	Use zone 4 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 5 Enable	N/A	9	N/A	3	6, 16	Use zone 5 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 6 Enable	N/A	10	N/A	3	6, 16	Use zone 6 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 7 Enable	N/A	11	N/A	3	6, 16	Use zone 7 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Zone 8 Enable	N/A	12	N/A	3	6, 16	Use zone 8 channels for voting. <b>No</b> = 0, <b>Yes</b> = 1
Override 1 Channel	N/A	13	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64

Type	Channel	Address Offset	Block Size	Read FC	Write FC	Notes
Override 1 Alarm	N/A	14	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> Alarm 2 = 1, Alarm 3 = 2
Override 2 Channel	N/A	15	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 2 Alarm	N/A	16	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> Alarm 2 = 1, Alarm 3 = 2
Override 3 Channel	N/A	17	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 3 Alarm	N/A	18	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> Alarm 2 = 1, Alarm 3 = 2
Override 4 Channel	N/A	19	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 4 Alarm	N/A	20	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> Alarm 2 = 1, Alarm 3 = 2
Override 5 Channel	N/A	21	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 5 Alarm	N/A	22	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1 = 0,</b> Alarm 2 = 1, Alarm 3 = 2




Type	Channel	Address Offset	Block Size	Read FC	Write FC	Notes
Override 6 Channel	N/A	23	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 6 Alarm	N/A	24	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2
Override 7 Channel	N/A	25	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 7 Alarm	N/A	26	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2
Override 8 Channel	N/A	27	N/A	3	6, 16	Create an override channel. <b>0</b> is disabled. 0 - 64
Override 8 Alarm	N/A	28	N/A	3	6, 16	Alarm for this override channel to use. <b>Alarm 1</b> = 0, Alarm 2 = 1, Alarm 3 = 2



# SECTION - 6 ENCLOSURE OPTIONS

## 6.1 Panel / Rack Mount Enclosure

The WX64 shown in Figure 6-1 is a half width 19" rack enclosure. It is supplied with hardware that allows mounting in either a full-width 19" rack style cabinet or it may be panel-mounted in a rectangular cutout. Only one 16-channel I/O option Board such as analog input or discrete relays, may be mounted directly to the back of the enclosure. Additional 16-channel I/O option boards must be located external from the assembly on another mounting plate. An extension I<sup>2</sup>C cable up to 10' is required for this purpose. Weight is approximately 7 pounds. Properly ground the enclosure and follow national and local electrical codes.




**Figure 6-1**

**Rack/Panel Mount**

**(19" Rack spreader plates & Panel mount bezel not shown)**

## 6.2 NEMA 4X Wall Mount Fiberglass Enclosure


The WX64 shown in Figure 6-2 is a fiberglass NEMA 4X wall mount enclosure. Eleven 16-channel I/O option boards, such as analog input or discrete relays, may be mounted inside this enclosure with the addition of a 0010-1269 expansion plate. It is suitable for mounting outdoors, but an above-mounted weather deflector shield is recommended. Weight is approximately 55 pounds. Figure 6.4 provides important warning information concerning correct grounding procedures for non-metallic enclosures. Conduit entries are not provided so installers may place entries as needed. Bottom or lower side areas are recommended. Care must be taken to avoid drilling into circuit boards mounted inside the enclosure. Properly ground the enclosure and follow national and local electrical codes.



**Figure 6-2**  
**NEMA 4X Wall Mount**

### 6.3 NEMA 7 Wall Mount Aluminum Enclosure

The WX64 shown in Figure 6-3 is an aluminum NEMA 4X / 7 wall mount enclosure designed for mounting into DIV 1&2 Groups B,C,D potentially hazardous areas. Five 16-channel I/O option PCB's, such as analog inputs or discrete relays, may be mounted inside this enclosure with the addition of a 0010-1284 expansion plate. It is suitable for mounting outdoors, but an above-mounted weather deflector shield is recommended. Weight is approximately 110 pounds. Properly ground the enclosure and follow national and local electrical codes.



**Figure 6-3**  
**NEMA 7 Wall Mount**



## GROUNDING OF EQUIPMENT AND CONDUIT

Ground in accordance with the requirements of the National Electrical Code.

Conduit hubs for metallic conduit must have a grounding bushing attached to the hub on the inside of the enclosure. Grounding bushings have provisions for connection of a grounding wire. Non-metallic conduit and hubs require the use of a grounding wire in the conduit. Grounding bushings are not required.

System grounding is provided by connection wires from all conduit entries to the subpanel or to other suitable point which provides continuity. Any device having a metal portion or portions extending out of the enclosure must also be properly grounded.

## TYPICAL GROUNDING ILLUSTRATIONS

### METALLIC CONDUIT

### NON-METALLIC CONDUIT





Figure 6-4

# SECTION - 7 WIRELESS OPTION

WX64's communication ports may be connected to a FHSS (Frequency Hopping Spread Spectrum) wireless radio modem shown in Figure 7-1. There are two different frequency options offered, 900 MHz and 2.4 GHz. 900 MHz is available in a single port modem (10-0364) or dual port modem (10-0365). 2.4 GHz is also available in a single port (10-0357) or dual port modem (10-0358). The dual port radio modems have two radio modules installed and can be used to receive and transmit data simultaneously. The radio kit options allow three separate modes of wireless operation. These are "Wireless Monitor" ([section 7.2](#)) accepting data from wireless OLCT 200 sensor transmitters, "Wireless ModBus Slave" ([section 7.3](#)) providing data to a ModBus *master* (*master* side of network requires additional radio), and "Wireless ModBus Master" ([section 7.4](#)) accepting wireless data from ModBus *slaves* (*slaves* side of network requires additional radio). When used in the "Wireless Receiver" mode, the radio must be connected to a port configured for **WIRELESS MONITOR**. "Wireless ModBus Master" mode requires the radio be connected to the WX64's RS-485 port configured for **MODBUS MASTER** and "Wireless ModBus Slave" mode connects it to the RS-485 port configured for **MODBUS SLAVE** ([Section 2.5.1.1](#)). It is important to remember RADIO SETUP functions described in [section 7.1](#) may be performed from the **COMMUNICATION SETTINGS** menu.

Each transceiver on a wireless network must have their **RADIO SETUP** menus configured to share the same hopping channel (0-32) and System ID (0-255) to communicate. All WX-series wireless transceivers utilize a Server-Client network where Clients synchronize their hopping to the Server. The Server transmits a beacon at the beginning of every hop (50 times per second). Client transceivers listen for this beacon, and upon hearing it, will indicate **InRange** with the LED on the radio modem board and synchronize their hopping with the Server. Each network should consist of only one Server. There should never be two servers on the same RF Channel number in the same coverage area, as the interference between the two servers will severely hinder RF communications. The Server must be in a powered location (as opposed to a battery-powered OLCT 200 utilizing a "sleep" mode) and Servers typically should be centrally located since all Clients must receive the beacon in order to communicate.



2.4 GHz Radio Modem      900 MHz Radio Modem

Note: Note:

10-0357 Has One Radio Module Installed

10-0364 Has One Radio Module Installed

10-0358 Has Two Radio Modules Installed


10-0365 Has Two Radio Modules Installed

Figure 7-1

## 7.1 Radio Setup Menu

Radio modules connected to the WX64's communication port may be configured

through the **RADIO SETUP** menu. Pressing the  key with the arrow pointing to the **Radio Setup** menu brings the **RADIO SETUP** menus to the screen (right side of Figure 7-2).



COM1-4 Menus are Identical

Figure 7-2



### 7.1.1 Hop Channel

**Hop Channel** may be set from 1-32 using the WX64 keypad and assigns the pseudo-random radio frequency hopping pattern. A transceiver will not go **InRange** of or communicate with a transceiver operating on a different **Hop Channel**.

### 7.1.2 System ID

**System ID** may be set from 1-255 using the WX64 keypad and is similar to a password character or network number and makes network eavesdropping more difficult. A transceiver will not go in range of or communicate with a transceiver operating on a different **System ID**.

### 7.1.3 Mode

**Mode** may be set for **CLIENT** or **SERVER**. For a single WX64 communicating to up to 64 battery powered OLCT 200 transceivers, Mode must = Server. To prolong battery life, OLCT 200s sleep most of the time and therefore may not be Servers. If an application calls for multiple WX64 locations, only one may be set for Server and all others must be Clients. This single Server transmits a beacon that all of the network's Clients synchronize to. **ONLY ONE SERVER PER NETWORK**.

## 7.2 Wireless Monitor Mode

**Wireless Monitor** mode is exclusively for wireless communication to our OLCT 200 wireless sensor transmitters (please visit [www.oldhamgas.com](http://www.oldhamgas.com) ). In Monitor mode the radio connects to the WX64's communication port and receives input data from up to 64 OLCT 200 wireless sensor transmitters. Wired and wireless inputs may be mixed between the WX64's 64 channels, so it is possible to also accept wired signals from analog input option PCBs described in [section 3.2](#).

Use the **WIRELESS MONITOR** setting shown in Figure 7-3 **ONLY FOR COMMUNICATION TO OLCT 200 WIRELESS TRANSCEIVERS**. [See section 7.4](#) for setting up wireless networks with other ModBus slave devices.

OLCT 200s transmit 200 counts for 0% and 1000 counts for 100% full scale readings so **Input Min/Max** menu values should be 200 & 1000. The **Remote ID** menu entry must match the **Remote Id** address setting in [the wireless OLCT 200 providing data to this WX64 channel](#). **Input Req** is typically set to VALUE but also allows a **Battery Voltage** entry into this field. Entering **Battery Voltage** causes the channel to display (and alarm) from battery voltage levels at this OLCT 200/RF. Voltage level of the 3.6 volt lithium battery in this OLCT 200 is also displayed on this screen.

Ch. 38 Data From			Ch. 38 Marker Menu		
Src	Wireless Monitor		Marker Enabled		Yes
Min Raw		200	Marker %		-16
Max Raw		1000	Mark as		IN CAL
Remote ID		10	Sensor Life		Yes
Interface		COM1			
Marker Menu		~			

Figure 7-3

## 7.2.1 Radio Status Alarms - Wireless Monitor Mode

When an WX64 channel's **INPUT DATA FROM** menu is set for **WIRELESS MONITOR**, in addition to processing the OLCT 200/RF's 10-bit "counts" value, it also receives status bits indicating **Communications Error**, **Low Battery** and **Calibration**.




Figure 7-4

### 7.2.1.1 Communications Error

Each channel's 30-minute trend screen (Figure 7-4) is very useful for diagnosing wireless problems since it indicates amount of time since the most recent transmission was received. The arrow on the bottom of the trend screen resets to far right each time a transmission is received by that channel. When not in alarm, OLCT 200s transmit every 5 minutes, so the arrow should never progress past the 5-minute interval. The WX64 activates the channel's **FAULT** alarm and indicates **ComErr** if no transmission has been received in 18 consecutive minutes. This interval can be adjusted in the communication settings menu for transmitters that are configured to communicate more often. [See section 2.5.1.12.](#)

### 7.2.1.2 Low Battery

Indicates the OLCT 200s integral 3.6V lithium D cell (part # 10-0293) has dropped to below 3.3V and should be replaced very soon. LoBatt is indicated on the WX64's LCD readout and the background color turns red. Relays are not energized by low battery conditions. The actual battery voltage of each wireless OLCT 200 may be seen in the **INPUT DATA FROM** screen described above in [section 7.2](#).

### 7.2.1.3 Calibrations

**Calibrations** performed at the OLCT 200/RF force a transmission of 75 counts (negative 15.62%), which may be indicated on the WX64's LCD readout by In Cal by using the "Marker Menu" described in [section 2.4.4.5](#). Alarms are inhibited while the "Marker Value" of -15.62% is activated.

## 7.3 Wireless ModBus Slave Mode

**Wireless ModBus** allows one or many WX64s to function as wireless ModBus slaves by connecting their RS-485 ModBus slave ports to a radio modem. These wireless networks require a ModBus master such as a DCS, HMI or another WX64 64 Channel Controller; also equipped with a radio modem. As in all WX-series wireless networks, one transceiver must be designated as Server and all others as Clients. No special configuration is required by the *master* or *slave* since this is a standard ModBus RTU network. However, radios must have the same **Hop Channel** and **System ID** settings to communicate.

The entire WX64 ModBus database, including registers and supported Function Codes, is documented in [section 5.3](#).

## 7.4 Wireless ModBus Master Mode

WX64 applications as a "Wireless ModBus master" are similar to the "Wireless Monitor" mode described in [section 7.2](#) and wiring to the radio modem is identical. The radio setup menus described in [section 7.1](#) may also be used for configuring hop channel and system ID settings. The difference is each Channel's **INPUT DATA FROM** menu must be configured with the correct **MODBUS** values to match the slave device instead of **Wireless Monitor**. Wired and wireless inputs may be mixed between the WX64's 64 channels so it is also possible to accept wired signals from analog input option PCB's described in [section 3.2](#).

This is a popular application when the ModBus slave is another remote WX64, WX16 or our WX4 controller available with built-in radio modem compatible with the WX64 Radio Kit. Other ModBus slave devices may also be converted to wireless by addition of another Radio Kit at the slave's location.

## 7.5 Antenna Selection

### 7.5.1 Dipole And Collinear Antennas

These antennas are connected to the radio via a length of coax cable. If the cable is larger than 6mm diameter (1/4 inch), do not connect the cable directly to the radio

connection on the WX64 enclosure. Thick cables have large bending radii and sideways force on the connector can cause a poor connection. Use a short flexible pigtail (such as our 1000-2308) between the thick cable and the radio.

The polarity of these antennas is the same as the main axis, and they are normally installed vertically. They can be mounted horizontally (horizontal polarity), however the antenna at the other end of the wireless link would need to be mounted perfectly parallel for optimum performance. This is very difficult to achieve over distance. If the antenna is mounted vertically, it is only necessary to mount the other antennas vertically for optimum “coupling” – this is easy to achieve.

Dipole and collinear antennas provide best performance when installed with at least 1 to 2 “wavelengths” clearance of walls or steelwork. The wavelength is based on the frequency:

Wavelength in meters =  $300 / \text{frequency in MHz}$

Wavelength in feet =  $1000 / \text{frequency in MHz}$

Therefore, 900 MHz antennas require at least 2/3 meter (2 feet) and 2.4GHz 15 cm (6 inches). Antennas may be mounted with less clearance, but radiation will be reduced. If the radio path is short, this won't matter. It is important the antenna mounting bracket be well connected to “earth” or “ground” for good lightning surge protection.

## 7.5.2 Yagi Antennas

Yagi antennas are directional along the central beam of the antenna. The folded element is toward the back and the antenna should be “pointed” in the direction of the transmission. Yagis should also be mounted with at least 1 to 2 wavelengths of clearance from other objects. The polarity of the antenna is the same as the direction of the orthogonal elements. For example, if the elements are vertical, the Yagi transmits with vertical polarity.

In networks spread over wide areas, it is common for a central unit to have an omnidirectional antenna and the remote units to have Yagi antennas. In this case, as the omnidirectional antenna will be mounted with vertical polarity, then the Yagis must also have vertical polarity. Care needs to be taken to ensure the Yagi is aligned correctly to achieve optimum performance.

Two Yagis can be used for a point-to-point link. In this case they can be mounted with the elements horizontally to give horizontal polarity. There is a large degree of RF isolation between horizontal and vertical polarity (approx -30dB), so this installation method is a good idea if there is a large amount of interference from another system close by transmitting vertical polarity.

An important mounting tip: If a Yagi has drainage holes in the dipole element, do not mount the antenna with the drainage holes.

### 7.5.3 Mounting Near Other Antennas

Avoid mounting your network's antenna near any other antenna even when the other antenna is transmitting on a different radio band. High RF energy of the transmission from a close antenna can "deafen" a receiver. This is a common cause of problems with wireless systems.

Because antennas are designed to transmit parallel to the ground rather than up or down, vertical separation between antennas is a lot more effective than horizontal separation. If mounting near another antenna cannot be avoided, mounting it beneath or above the other antenna is better than mounting beside it. Using different polarity to the other antenna (if possible) will also help to isolate the RF coupling.

### 7.5.4 Coax Cables

If a coax cable connects to the antenna via connectors, it is very important to weatherproof the connection using our 1000-2314 or equivalent sealing tape. Moisture ingress into a coax cable connection is the most common cause of problems with antenna installations. A three layer sealing process is recommended – an initial layer of electrical PVC tape, followed by a second layer of self-vulcanizing weatherproofing tape (1000-2314), with a final layer of electrical PVC tape.

Allowing a drip "U loop" of cable before the connection is also a good idea. The loop allows water to drip off the bottom of the U instead of into the connection, reduces installation strain and provides spare cable length in case later the original connectors need to be removed, the cable cut back and new connectors fitted.

Avoid installing coax cables together in long parallel paths. Leakage from one cable to another has a similar effect as mounting an antenna near another antenna.

## 7.6 Surge Protection & Grounding

Voltage surges can enter the WX64 via the antenna connection, power supply connection, connections to other equipment and even the "earth" or "ground" connection. Surges are electrical energy following a path to earth, and the best protection is achieved by "draining" the surge energy to earth via an alternate path. Wireless devices need to have a solid connection to earth via a ground stake or ground grid if the soil has poor conductivity. Solid connection means a large capacity conductor (not a small wire) with no coils or sharp bends. All other devices connected to the WX64 need to be grounded to the same ground point. There can be significant resistance between different ground points leading to very large voltage differences

during lightning activity. As many wireless units are damaged by earth potential surges due to incorrect grounding as are damaged by direct surge voltage.

It is very difficult to protect against direct lightning strikes but the probability of a direct strike at any one location is very small. Unfortunately, power line surges and electromagnetic energy in the air can induce high voltage surges from lightning activity several miles away.

### 7.6.1 Antenna Grounding

Electromagnetic energy in the air will be drained to ground via any and every earth path. An earth path exists between the antenna and the WX64, and to protect against damage this earth path current must be kept as small as possible. This is achieved by providing better alternate earth paths. It is important to ground the antenna to the same ground point as the WX64. Antennas are normally mounted to a metal bracket that should be grounded to the WX64 earth connection. Surge energy induced into the antenna will be drained first by the mount's ground connection, second by the outside shield of the coax cable to the ground connection on the radio and third by the internal conductor of the coax cable via the radio electronics. This third earth path causes damage unless the other two paths provide a better earth connection allowing surge energy to bypass the electronics.

When an antenna is located outside of a building and outside of an industrial plant environment, external coax surge diverters are recommended to further minimize the effect of surge current in the inner conductor of the coax cable.

Coax surge diverters have gas-discharge element that breaks down in the presence of high surge voltage and diverts any current directly to a ground connection. A surge diverter is not normally required when the antenna is within a plant or factory environment, as the plant steelwork provides multiple parallel ground paths and good earthing will provide adequate protection without a surge diverter.

### 7.6.2 Connections To Other Equipment

Surges can enter the wireless unit from connected devices, via I/O, serial or Ethernet connections. Other data devices connected to the wireless unit should be well grounded to the same ground point as the wireless unit.

Special care needs to be taken where the connected data device is remote from the wireless unit requiring a long data cable. As the data device and the wireless unit cannot be connected to the same ground point, different earth potentials can exist during surge conditions.

There is also the possibility of surge voltages being induced on long lengths of wire from nearby power cables. Surge diverters can be fitted to the data cable to protect against surges entering the wireless unit.

The same principle applies when the I/O device is not close to the wireless unit, thus, the risk of surge increases. Surge diverters for I/O wiring are available to protect the wireless unit.

## SECTION - 8 WEBPAGE

All WX64 controllers come standard with an embedded webpage. The webpage gives remote access to view and configure parameters inside the controller. There are two levels of security clearance. The first level allows the user to view channel status and configuration while the second level allows the user to change configuration parameters directly from the computer.

The webpage requires a modern web browser. Supported browsers include Internet Explorer 8\*, Google Chrome, or Mozilla Firefox 2+. Viewing pages in an outdated browser will result in improperly drawn pages.

In order to view the webpage, the user must know the IP address or, if DHCP enabled, the controller's hostname. This information can be viewed from the Network Settings menu ([see section 2.5.3](#)). Once the name or address is entered into a browser, a pop-up box asks the user for the username and password. The name and password are fixed: the **NAME: admin** and the **PASSWORD: controller64**. After access is gained, the user will be able to see channel data, event logs and configuration. If a parameter needs to be changed, the user must login before the controller will accept the change. This login password can be changed in the Security menu under ModBus Lock Code ([see section 2.6.3](#)). The default ModBus Lock Code is **1234**.

\* Internet Explorer does not allow access to hostnames that contain a '\_' character.

## 8.1 System Screen

The System screen shown below (Figure 8-1) displays all active channels at once. It is capable of displaying 16, 32, 48 or 64 channels depending on the controller's configuration. This screen, very similar to the Main Data screen, displays measurement name and uses colored cells that flash with new alarms to indicate alarm conditions. Once the alarms have been acknowledged by an operator the cell will remain the appropriate color but will stop flashing, showing the alarm has been acknowledged.

The five standard relays states are shown at the bottom of the screen. The boxes duplicate the LED behavior as seen when looking at the unit. A flashing box indicates an unacknowledged relay, a red box indicates an energized (de-energized for failsafe) relay.

While in the System screen, use the mouse to click on any cell to go directly to that channel's individual data screens. The unused channels are grayed out when turned off.

Viewing only channels belonging to a certain zone can be enabled using the zone drop-down box. Selecting a zone will cause channels belonging to other zones to dim.

The System screen is updated automatically every 15 seconds.



Figure 8-1



## 8.2 Zone Screen

The webpage's Zone screen (Figure 8-2) displays the eight possible zones simultaneously [see section 1.3.5](#). If an alarm condition occurs, the user will be able to quickly see in what zone the situation is occurring. Each active zone is divided into alarm levels, which are green until an alarm is present. Inactive zones and alarm levels are grayed out. If an alarm should occur, the zone name field will flash and the corresponding box in the assigned zone will turn the color of the alarm that is present or alternate if two different colors are present. Once the alarm has been acknowledged, the name field will stop flashing.

To display all the channels included in any zone, use the mouse to click that zone box. The System screen will appear with all the channels that are included in the selected zone displayed in color and the channels that are not in the selected zone dimmed.

The zone screen is updated automatically every 15 seconds.



Figure 8-2

## 8.3 Channel Screen

The Channel screen shown in Figure 8-3 displays a 24-hour trend of input data for the channel selected. Vertical tick marks are each hour and horizontal tick marks are each 10% of full scale. Colored lines indicate alarm levels. Since each data point must be collected for several minutes before it may be displayed, it is likely input values will fluctuate during this interval. Therefore, MAX, MIN and AVERAGE values are stored in the controller for each subinterval. Checking the Min, Max and Avg box in the lower left corner turns the respective lines on and off. If there is no trend data available, the corresponding section of the graph will be grayed out. This will occur on power interruptions.

The top portion of each trend screen indicates channel number, real time reading in engineering units, and measurement name. When a channel reaches alarm state, the colored bar changes to the color that represents that alarm level and flashes. Once the alarm is acknowledged, the bar stops flashing.


The top portion of the page updates automatically every 15 seconds. The trend is updated when a channel is changed or the 'Refresh Trend' button is pressed.



Figure 8-3

## 8.4 Event Log Screen

Displays the last 255 events logged in the WX64. The events are logged in a first in first out format, in non-volatile memory, so a SD card is not necessary to view the event log. These events include Alarms In and Out, Alarm Resets, Calibrations, System and Cold Boots, and Communication and Configuration Error. The events are time and date stamped, and if channel-specific, the number is shown in the right column in Figure 8-4.



The screenshot shows the Event Log screen with a dark background and white text. At the top, there are menu options: SYSTEM, ZONE, CHANNEL, EVENT LOG (highlighted), and CONFIGURE. In the top right corner, it says 'logged in: [redacted]'. Below the menu is a table with the following columns: Date, Time, Event, and Channel. The table contains 25 rows of event data, all dated 10/26/2010 at 13:56. The events listed are Alarm reset, Alarm 2 in, Alarm 1 in, and Alarm 2 in, with channel numbers ranging from 17 to 32.

Date	Time	Event	Channel
10/26/2010	13:56	Alarm reset	—
10/26/2010	13:56	Alarm 2 in	18
10/26/2010	13:56	Alarm 1 in	18
10/26/2010	13:56	Alarm 2 in	17
10/26/2010	13:56	Alarm 1 in	17
10/26/2010	13:56	Alarm 2 in	32
10/26/2010	13:56	Alarm 1 in	32
10/26/2010	13:56	Alarm 2 in	31
10/26/2010	13:56	Alarm 1 in	31
10/26/2010	13:56	Alarm 2 in	30
10/26/2010	13:56	Alarm 1 in	30
10/26/2010	13:56	Alarm 2 in	29
10/26/2010	13:56	Alarm 1 in	29
10/26/2010	13:56	Alarm 2 in	28
10/26/2010	13:56	Alarm 1 in	28
10/26/2010	13:56	Alarm 2 in	27
10/26/2010	13:56	Alarm 1 in	27
10/26/2010	13:56	Alarm 2 in	26
10/26/2010	13:56	Alarm 1 in	26
10/26/2010	13:56	Alarm 2 in	25
10/26/2010	13:56	Alarm 1 in	25
10/26/2010	13:56	Alarm 2 in	24
10/26/2010	13:56	Alarm 1 in	24
10/26/2010	13:56	Alarm 2 in	23
10/26/2010	13:56	Alarm 1 in	23
10/26/2010	13:56	Alarm 2 in	22
10/26/2010	13:56	Alarm 1 in	22

Figure 8-4

## 8.5 Configure

The configuration pages allow viewing and editing of most system parameters. The exceptions are communication and security settings, which must be set from the unit's keypad interface. All changes made to the configuration parameters will not be saved until the user has entered the correct login password.

### 8.5.1 Alarm Outputs

The screenshot displays the 'CONFIGURE' page of the WX64 system. The interface is divided into two main columns for 'Standard Relay 1' and 'Standard Relay 2'. Each column contains a list of parameters with corresponding input fields or checkboxes. The 'Standard Relay 1' column includes: A1 Voter (1), A2 Voter (0), A3 Voter (0), Acknowledge (\*), Failsafe (\*), and Zones 1 through 8 (all \*). Below these are four 'Override' sections, each with a 'Channel' field (set to 0) and an 'Alarm' field (set to Alarm 1). The 'Standard Relay 2' column includes: A1 Voter (0), A2 Voter (1), A3 Voter (0), Acknowledge (\*), Failsafe (\*), and Zones 1 through 8 (all \*). Below these are four 'Override' sections, each with a 'Channel' field (set to 0) and an 'Alarm' field (set to Alarm 1). The top navigation bar includes 'SYSTEM', 'ZONE', 'CHANNEL', 'EVENT LOG', and 'CONFIGURE', with a 'logged in' indicator on the right.

Figure 8-5

## 8.5.2 Channel Configuration

The screenshot shows the 'CONFIGURE' tab for channel 1. It is divided into two main sections: 'Alarms' and 'Configure'.

**Alarms Section:**

- Alarm 1:** Setpoint: 20,000; Latching: \*; Trip On: High; On Delay (seconds): 0; Off Delay (minutes): 0; Horn Drive: \*
- Alarm 2:** Setpoint: 40,000; Latching: \*; Trip On: High; On Delay (seconds): 0; Off Delay (minutes): 0; Horn Drive: \*; Color: Red
- Alarm 3:** Enabled: \*; Setpoint: 60,000; Latching: \*

**Configure Section:**

- Channel Enabled: \*
- Tag: Measurement Name
- Engineering Units: PCTLEL
- Zero: 0.000
- Span: 25,000
- Decimal Places: 0
- Zone: Zone 1
- Deadband: 1,000
- Data From: Source: Analog Input; Min Raw: 800; Max Raw: 4000; Filter Sample Count: 10; Local Cal: On
- Fault: Fault Level: -2,500

Figure 8-6

## 8.5.3 Copy Channels

The screenshot shows the 'Copy Channels' interface. At the top, it says 'Copy from channel 63' and 'to channels'. Below this is a grid of channel numbers from 01 to 64. The numbers 60, 61, 62, and 63 are highlighted in red, indicating they are the source channels. A 'Copy' button is located at the bottom center.

01	17	33	49
02	18	34	50
03	19	35	51
04	20	36	52
05	21	37	53
06	22	38	54
07	23	39	55
08	24	40	56
09	25	41	57
10	26	42	58
11	27	43	59
12	28	44	60
13	29	45	61
14	30	46	62
15	31	47	63
16	32	48	64
60	61	62	63
Stop	Stop	Stop	Stop

Figure 8-7

## 8.5.4 Programmable Relays

SYSTEM ZONE CHANNEL EVENT LOG CONFIGURE Logged In: **Admin**

Programmable Relay 1

**Programmable Relay board not found!**

A1 Votes	<input type="text" value="1"/>	Override 1	Channel: <input type="text" value="0"/>
A2 Votes	<input type="text" value="0"/>	Alarm: <input type="text" value="Alarm 1"/>	
A3 Votes	<input type="text" value="0"/>	Override 2	Channel: <input type="text" value="0"/>
Acknowledge	<input type="checkbox"/>	Alarm: <input type="text" value="Alarm 1"/>	
FailSAFE	<input type="checkbox"/>	Override 3	Channel: <input type="text" value="0"/>
Zone 1	<input type="checkbox"/>	Alarm: <input type="text" value="Alarm 1"/>	
Zone 2	<input type="checkbox"/>	Override 4	Channel: <input type="text" value="0"/>
Zone 3	<input type="checkbox"/>	Alarm: <input type="text" value="Alarm 1"/>	
Zone 4	<input type="checkbox"/>	Override 5	Channel: <input type="text" value="0"/>
Zone 5	<input type="checkbox"/>	Alarm: <input type="text" value="Alarm 1"/>	
Zone 6	<input type="checkbox"/>	Override 6	Channel: <input type="text" value="0"/>
Zone 7	<input type="checkbox"/>	Alarm: <input type="text" value="Alarm 1"/>	
Zone 8	<input type="checkbox"/>	Override 7	Channel: <input type="text" value="0"/>
		Alarm: <input type="text" value="Alarm 1"/>	
		Override 8	Channel: <input type="text" value="0"/>
		Alarm: <input type="text" value="Alarm 1"/>	

Figure 8-8

## 8.5.5 System Configuration

SYSTEM ZONE CHANNEL EVENT LOG CONFIGURE Logged In: **Admin**

System Config:

Name	<input type="text" value="DNR-72-1000"/>	Zone 1 Name	<input type="text" value="Zone 1"/>
Date	<input type="text" value="10"/> / <input type="text" value="26"/> / <input type="text" value="2010"/>	Zone 2 Name	<input type="text" value="Zone 2"/>
Time	<input type="text" value="14"/> : <input type="text" value="5"/> : <input type="text" value="36"/>	Zone 3 Name	<input type="text" value="Zone 3"/>
Channel Count	<input type="text" value="64"/>	Zone 4 Name	<input type="text" value="Zone 4"/>
Cell Purge Time (min)	<input type="text" value="1"/>	Zone 5 Name	<input type="text" value="Zone 5"/>
Warmup Time (min)	<input type="text" value="1"/>	Zone 6 Name	<input type="text" value="Zone 6"/>
Zone Screen Enabled	<input type="checkbox"/>	Zone 7 Name	<input type="text" value="Zone 7"/>
Block Negative	<input type="checkbox"/>	Zone 8 Name	<input type="text" value="Zone 8"/>

Figure 8-9

## 8.5.6 Configuration Upload/Download

The configuration upload/download page allows transferring system configuration to or from the unit via the webpage. When the download link is clicked, the unit saves the current configuration into a file and transfers it to the user. It should be saved as a .cfg file. When uploading configuration, select a .cfg file and press upload. Note that the maximum length of a filename for an uploaded file is 28 characters. After a successful upload, the unit will restart and the webpage will attempt to refresh after 30 seconds.



Figure 8-10





# SECTION - 9 TROUBLESHOOTING

## 9.1 Channel Errors

The following errors indicate potential hardware or configuration problems. If an error occurs, a message is displayed for that channel.

### 9.1.1 Comm Error

Comm Error can occur for ModBus or wireless channels. This error indicates the data was not received. Comm Error can indicate a timeout or an invalid reply from a device. Check communication settings for the port used as well as the **Data from** menu for that channel. The ports themselves can be tested from the **Diagnostics** menu.

### 9.1.2 Config Error

Config error can occur for ModBus or wireless channels only. This error indicates that the Interface selected is configured for something else. For example, if **COM1** is set to ModBus slave and a channel 1 is set with a **Source of ModBus 16bit** and an **Interface of COM1**. To correct this, either edit the COM port in **Communication Settings** menu or edit the channel's **Interface** in the **Data From** menu.

### 9.1.3 I/O Error

I/O Error indicates a problem communicating with the analog input boards. This error will affect an entire group of 16 channels at a time, assuming they are all set up for analog input. Check wiring from the Main I/O Board to the affected Analog Input board. Verify that the analog input board is set up for the correct channel group. Only a single input board in a system can be set to use each channel group. See **I/O Board Config** in the **Diagnostics** menu.

## 9.2 Reset To Factory Defaults

The WX64 configuration can be reset to factory defaults. This is done through the **Coldboot** menu shown in Figure 9-1. To access the Coldboot menu, hold the Edit key and cycle power. The Edit key can be released once the *Loading Configuration Data* progress bar appears. If an SD Card is installed, this menu will allow backing up the current configuration before starting the Coldboot.



Figure 9-1





## **EUROPEAN PLANT AND OFFICES**

Z.I. Est – rue Orfila CS 20417 – 62027 Arras Cedex FRANCE

Tél: +33 (0)3 21 60 80 80 – Fax: +33 (0)3 21 60 80 00

Website: <http://www.oldhamgas.com>

### **AMERICAS**

Tel: +1-713-559-9280  
Fax: +1-281-292-2860  
[americas@oldhamgas.com](mailto:americas@oldhamgas.com)

### **ASIA PACIFIC**

Tel: +86-21-3127-6373  
Fax: +86-21-3127-6365  
[sales@oldhamgas.com](mailto:sales@oldhamgas.com)

### **EUROPE**

Tel: +33-321-608-080  
Fax: +33-321-608-000  
[info@oldhamgas.com](mailto:info@oldhamgas.com)