#### **TOSHIBA**

# Field Intelligent Device Series-Mount Anywhere series-Flanged

# ELECTROMAGNETIC FLOWMETER

LF664/LF620 LF664/LF622

20"to 78"(500 to 1950mm)

# Introduction

The electromagnetic flowmeter uses Faraday's Law of electromagnetic induction to measure the process flow. The device consists of two units: a detector, through which the fluid to be measured flows and in which low-level signals proportional to flow rates are obtained; and a converter, which supplies excitation current to the detector, and amplifies the signals from the detector and then processes and converts the signals into the 4-20 mAdc current signal or communication signal. The meter features a Mount-Anywhere magnetic field distribution technology, the meter is highly immune to upstream flow disturbances. Combined with a multi-functional converter LF622 (separate type) equipped with its patented Noise-Sentry original noise- suppression circuit and advanced algorithms. The LF664 has a very high tolerance to noise, giving the unit a very stable output even for slurry fluid measurement. IR (Infrared) switches enable parameter setting of the converter without removing the cover. Flow direction can be set in either way, and its unique 128 x 128 dot matrix LCD display allows the LCD to be rotated electronically to 90, 180 and 270 degrees without opening the cover.

- \* HART protocol (Highway Addressable Remote Transducer) is a communication protocol for industrial sensors recommended by the HCF (HART Communication Foundation).
  - \*\* DevComm2000 Smart Device Communicator available for performing HART device configurations on PC or laptop is available through the supplier..
- \* PROFIBUS is the communications protocol for factory and process automation that the PROFIBUS Organization recommends. Instead of analog control with a conventional analog signal (4-20 mA), it is fieldbus which digitizes all signals. Flowmeters support PROFIBUS-PA.
- \* Modbus is the communication protocol that Modicon Inc. developed. Physical layer is RS485.




Figure 1. Configuration




Figure 2. LF664 Mount-Anywhere series Flowmeters





For HR lined flowmeter

# **Specifications**

# ■ Overall Specifications

**Measurement range in terms of flow velocity:** 1.0 ft/s to 32.8ft/s (0.3 m/s to 10 m/s).

#### Accuracy:

# < 20" and 24" (500 mm and 600 mm) > $\pm 0.3$ % of Rate \*1.

- \* This pulse output error result is established under standard operating conditions at Toshiba's admitted flow calibration facility.(NIST Traceable)
- \*<sup>1</sup> Individual meter measurement error may vary up to ±0.5 % of Rate at 3.28 ft/s (1.0 m/s) or more and ± 0.3% of Rate ±0.079 inch/s (2 mm/s) at 3.28 ft/s (1.0 m/s) or less.
- \* Current output: plus  $\pm 8\mu A$  (0.05% of span.)
- \*1 Refer to individual calibration data for each individual meter's measurement error.

# < 28" to 78" (700 mm to 1950 mm) > $\pm$ 0.5 % of Rate $^{*2}$ .

- \*<sup>2</sup> This pulse output error result is established under standard operating conditions at Toshiba's admitted flow calibration facility.(NIST Traceable)
- \* $^2$  Individual meter's measurement error may vary up to  $\pm$  0.8 % of Rate at 3.28 ft/s (1.0 m/s) or more and  $\pm$  0.4% of Rate  $\pm$ 0.157 inch/s (4mm/s) at 3.28 ft/s (1.0 m/s) or less.
- \* $^2$  Current output: plus  $\pm 8\mu A$  (0.05% of span.)
- \*<sup>2</sup> Refer to individual calibration data for each individual meter's measurement error.

Fluid conductivity: 5µS/cm minimum.

### Fluid temperature:

14 to 140 °F (-10 to +60 °C):

For meter size 20" to 36" (500mm to 900mm)

 $14 \text{ to } 104 \,^{\circ}\text{F} (-10 \text{ to } +40 \,^{\circ}\text{C})$ :

For meter size 40" (1000mm) and over

Natural Rubber lined flow meter

23 to 176°F (-5 to +80 °C):

Hard Rubber lined flow meter

Ambient temperature: 14 to 140 °F (-10 to +60 °C)

#### **Structure:**

Standard — IP 67 and NEMA 4X Watertight

**Option** — IP68 and NEMA 6P Submersible type allows for accidental submergence up to 15m for

48hours. This option is available when Natural

Rubber or Hard Rubber liners are selected.

#### **Power consumption:**

10W (14VA) or less (at AC100V and Excitation current 0.2A)

17W (24VA) or less (with communication)

# Approved hazardous location certifications:

Model: LF664/LF620F and LF664/LF622F

cFMus Nonincendive for use in

hazardous (classified) locations:

Class I, II, III, Division 2, Groups A-G

#### **Detector and converter combination:**

LF664/LF620F: Combined type with Ex approval of Class I, II, III, Division 2 (cFMus).

LF664/LF622F: Separate type with Ex approval of Class I, II, III, Division 2 (cFMus).

#### **Mount-Anywhere Technology:**

With TOSHIBA's unique magnetic field distribution technology the meter is highly immune to upstream flow disturbances.

<20" and 24" (500mm and 600mm)>

A minimum of 1D(diameter) length of upstream straight pipe from the flange is required to maintain the specific performance.

<28" to 78" (700mm to 1950mm)>

A minimum of 3D (diameters) length of upstream straight pipe from the flange is required to maintain the specification performance.

**Note:** The test results were obtained and demonstrated at TOSHIBA's admitted flow calibration facility.

#### Model LF664 Detector

Mounting style: Flanged connection type

#### Fluid pressure:

−0.1Mpa to the pressure limited by flange standard.

#### **Connection flange standards:**

ASME B 16.5 class 150 : 20" and 24" ( 500 and 600 mm) AWWA class D : 28" and over ( 700 mm and over)

#### **Principal materials:**

Case — Carbon Steel

#### Linings —

Hard Rubber (NSF certified)

Natural Rubber

#### Electrodes —

Type-Super smooth, polished with Self-cleaning finish and non stick shape

AISI 316L stainless steel (standard)

Titanium (opt)

Hastelloy C-276 equivalent (opt)

#### Grounding rings (option) —

AISI304, AISI316, Titanium, Hastellov C-276 equivalent

**Note:** See Table 3 for optional materials and other related information.

# Measuring tube material — 304 stainless steel

#### Coating:

Polyurethane, gray color(std) Black tar epoxy resin coating 0.5mm (opt) for IP68 and NEMA6P

# Cable connection port (for separate type detectors) Cable gland:

Not provided, 1/2-14NPT male threads, Cable glands not provided.

**Dimensions and weight**: See figure 3,4,5 and 6

## ■ Model LF620 and LF622 converters

#### Input signals

**Analog signal** — the voltage signal from detector, proportional to process flow rate (for LF622 separate type converter).

#### Digital input DI

Signal type: 20 to 30Vdc voltage signal

Input resistance:  $2.7k\Omega$ Number of inputs: one point

**Note:** DI cannot be used with the Modbus communication.

**DI function** — One of the following functions can be assigned to the DI signal.

Range switching — Selects either the higher or lower range in the unidirectional or bidirectional 2-range setting.

**Totalizer control** — 'Starts and stops' or 'Rest and start' the built-in totalizer.

**Fixed-value outputs** —Outputs fixed-values for current and pulse outputs for loop check.

**Zero adjustment** — Executes zero adjustment (on-stream at zero flow rate).

#### **Output signals**

#### **Current output:**

4-20mAdc (load resistance 0 to  $750\Omega$ )

**Note:** The current output cannot be used with the PROFIBUS-PA communication. (Refer table 5 for details)

**Digital outputs** — Two points are available as follows.

#### **Digital output DO1:**

Output type: Transistor open collector Number of outputs: One point

Output capacity: 30Vdc, 200mA maximum

**Note:** DO1 cannot be used if Modbus communication connection is 3 lines. (Refer table 5 for details)

#### Digital output DO2:

Output type:

Solid-state relay output (non polarity)

Number of outputs: One point

Output capacity: 150Vdc, 150mA maximum or 150Vac (peak to peak), 100mA maximum

**Note:** DO2 cannot be used with the Modbus communication. (Refer table 5 for details)

**DO1 and DO2 functions** — One of the following functions can be assigned to DO1 and/or DO2.

• Pulse output (available only for DO1, DO2)

Pulse rate: MAX 10kHz (10000pps)(DO1) MAX 100Hz (100pps)(DO2)

(Over 1kpps, auto-setting)

Pulse width: 0.5 to 500ms (but less than half of the period for 100% flow rate)

**Note:** The same and simultaneous pulse is not available between DO1 and DO2.)

- Multi-range selection outputs (Note 1)
- High, High high, Low, and/or Low low alarm outputs (Note 2)
- Empty pipe alarm output (Note 2)
- Preset count output
- Converter failure alarm output

**Note 1:** Two outputs (DO1 and DO2) are needed for 4-range switching and forward/reverse 2-range switching.

**Note 2:** Normal Open (default set) or Normal Close is selected for alarm outputs when programming.

When power failure occurs, unit will be fault to Normal Open.

#### **Communications output**:

• **HART (std.)** — Digital signal is superimposed on 4–20mAdc current signal as follows:

Conforms to HART protocol Load resistance: 240 to  $750\Omega$ 

Load capacitance: 0.25µF maximum Load inductance: 4mH maximum

• PROFIBUS (opt.)

Protocol: PROFIBUS-PA Baud rate: 31.25kbps Bus voltage: 9-30VDC

Consumption electric current of bus: less than 16mA

Manufacture Ident-No.: 093B<sub>HEX</sub> Standard Ident-No.: 9740<sub>HEX</sub>

Slave address: 0-126 (Default address is 126) Profile: Profile Ver.3.01 for Process Control

**Devices** 

Function blocks: AI(Flow) $\times 1$ , Totalizer $\times 1$ 

#### •Modbus (opt.)

Physical layer: RS485 Protocol: Modbus Mode: RTU

Baudrate: 4800, 9600, 19200bps

Data length: 8bit

Parity bit: None, Odd, Even

Stop bit : 1bit, 2bit Error check : CRC-16

Max. station number: 32(with Master device)

Max. cable length: 1.2km (Note)

**Note:** This length is specification of 3 line connection.

#### LCD display:

Full dot-matrix 128×128 dot LCD display (back-light provided)

A parameter change will rotate the display.

**Parameter settings** — Parameters can be set as follows:

- **IR Switches**: Three key switches are provided to set configuration parameters.
- Digital communication: HART, PROFIBUS or Modbus is needed to set parameters.
- Zero adjustment: Zero point adjustment can be started by pressing the switch in the converter
- **Damping:** 0.1 to 60 seconds (selectable in one second increments)

**"Field re-verification" Mag-Prover**— Toshiba's Zero span calibration tool allows unit to be re-calibrated and verified using an internal software program (For more information contact Toshiba International Corp.)

#### Conditions when power fails:

Parameter setting values are stored in non-volatile memory and the values will be restored when the power returns to normal condition. The outputs and display will remain as follows when power fails.

Current output: 0mAdcDigital output: OFFLCD display: No display

HART: No communication
 PROFIBUS: No communication
 Modbus: No communication

# Power supply:

One of the following can be selected:

• 100 to 240Vac, 50/60Hz (allowable voltage 80 to 264Vac) 110Vdc (allowable voltage 90 to 130Vdc)

• 24Vdc (allowable voltage 18 to 36Vdc)

#### **Surge protection:**

Arresters are installed in the power supply and a current signal output circuit to help protect the meter from lightning and improve personnel safety.

Case: Aluminum alloy (equal to IP 67)

#### **Coating:**

Acrylic resin-baked coating, pearl-gray colored

#### **Cable connection port:**

#### Cable glands —

LF620 and LF622 without cFMus Approval:

Provided as standard, outer diameter of cable  $\phi$  11~13mm Material Nylon 66 G (PF) 1/2 male threads.

LF620F and LF622F with cFMus Approval:

Not provided, 1/2–14NPT male threads are required.

#### Applicable diameter —

0.433 to 0.512 inch (11 to 13mm)

Note: When PROFIBUS option is specified, cable gland size is  $\phi$  6~8mm for signal cable,  $\phi$  11~13mm for power cable

#### **Vibration resistance:**

No resonance to the following levels of vibration:

- 10 to 150Hz with acceleration of 9.8m/s<sup>2</sup>
- Vibration of 30Hz with 29.4 m/s<sup>2</sup> in 4h in each direction will not cause any defect to unit.

**Note:** Avoid using the flowmeter in an environment with constant vibration.

#### **Dimensions and Weights:**

See Figure 7 (for Separate type)

#### MTBF:

Converter: 220,000 hours (25 years) at 77 °F (25 °C)

based on strict military specification

MIL-HDBK-217F


Detector: 350,000 hours (40 years) at 77 °F (25 °C)

based on strict military specification

MIL-HDBK-217F

# Installation

# Dimensions




ASME B 16.5 class 150 dimensions:

Dimension without grounding ring

Meter size (inch)	L1 (inch)	L2 (inch)	L3 (inch)	Number of Bolts	Weight (lbs)
20"	23.62	17.54	31.29	20	approx. 530
24"	23.62	19.61	35.61	20	approx. 710

Meter size (inch)	L1 (inch)	L2 (inch)	L3 (inch)	Number of Bolts	Weight (lbs)
20"	24.09	17.54	31.29	20	approx. 530
24"	24.09	19.61	35.61	20	approx. 710

Figure 3. LF664/LF620F combined type flow meters. Meter sizes 20" (500mm) and 24" (600mm)




# AWWA class D dimensions:

Dimension without grounding ring

Meter size (inch)	L1 (inch)	L2 (inch)	L3 (inch)	Number of Bolts	Weight (lbs)
28	27.56	21.79	40.04	28	approx. 640
30	29.53	22.80	42.17	28	approx. 710
32	31.50	23.92	44.79	28	approx. 840
36	35.43	25.93	48.93	32	approx. 1100

Meter size (inch)	L1 (inch)	L2 (inch)	L3 (inch)	Number of Bolts	Weight (lbs)
28	28.03	21.79	40.04	28	approx. 640
30	30.00	22.80	42.17	28	approx. 710
32	31.97	23.92	44.79	28	approx. 840
36	35.90	25.93	48.93	32	approx. 1100

Figure 4. LF664/LF620F combined type flow meters. Meter sizes 28" (700mm) and 36" (900mm)




# ASME B 16.5 class 150 dimensions:

Dimension without grounding ring

Meter size (inch)	L1 (inch)	L2 (inch)	L3 (inch)	Number of Bolts	Weight (lbs)
20"	23.62	16.24	29.99	20	approx. 530
24"	23.62	18.31	34.31	20	approx. 710

Meter size (inch)	L1 (inch)	L2 (inch)	L3 (inch)	Number of Bolts	Weight (lbs)
20"	24.09	16.24	29.99	20	approx. 530
24"	24.09	18.31	34.31	20	approx. 710

Figure 5. LF664 Detector Meter sizes 20" (500mm) and 24" (600mm)



AWWA class D dimensions:

Dimension without grounding ring

Meter size (inch)	L1 (inch)	L2 (inch)	L3 (inch)	Number of Bolts	Weight (lbs)	
28	27.56	20.49	38.74	28	approx. 640	
30	29.53	22.62	41.99	28	approx. 710	
32	31.50	22.62	43.49	28	approx. 840	
36	35.43	24.63	47.63	32	approx. 1100	
40	39.37	26.75	52.13	36	approx.1300	
42	41.34	30.75	57.25	36	approx.1500	
48	47.24	30.75	60.50	44	approx.2050	
54	55.12	33.74	66.87	44	approx.2600	
60	59.06	39.74	76.24	52	approx.3450	
66	62.99	39.74	79.74	52	approx.4400	
72	70.87	42.78	86.03	60	approx.4950	
78	78.74	45.91	92.41	64	approx.6400	

Meter size (inch)	L1 (inch)	L2 (inch)	L3 (inch)	Number of Bolts	Weight (lbs)
28	28.03	20.49	38.74	28	approx. 640
30	30.00	22.62	41.99	28	approx. 710
32	31.97	22.62	43.49	28	approx. 840
36	35.90	24.63	47.63	32	approx. 1100
40	39.84	26.75	52.13	36	approx.1300
42	41.81	30.75	57.25	36	approx.1500
48	47.71	30.75	60.50	44	approx.2050
54	55.59	33.74	66.87	44	approx.2600
60	59.53	39.74	76.24	52	approx.3450
66	63.46	39.74	79.74	52	approx.4400
72	71.34	42.78	86.03	60	approx.4950
78	79.21	45.91	92.41	64	approx.6400

Figure 6. LF664 Detector Meter sizes 28" (700mm) and 78" (1950mm)





Figure 7. Separate type converter LF622 and LF622F

#### **■** External Connections

• Combined type LF664/LF620 flowmeter



\*1 Locate an external double-pole power switch on the power line near the flowmeter within easy reach of operation. Use the appropriate switch rating as shown below:

Switch rating: 250Vac, 6A or more In rush current: 15A or more

Figure 8. Combined type LF664/LF620F flowmeter Wiring Diagram

## • Separate type LF664/LF622 flowmeter




Figure 9. Separate type LF664/LF622F flowmeter wiring Diagram

Table 1. LF620, LF620F, LF622 and LF622F Converters Signal Table

Symbol	Description	Cable
L1 (+) L2 (-)	Power supply	Power cable
GND	Ground (for arrester)	
FG	Frame ground	
DI	Digital Input (20~30Vdc)	
DO1	Digital Output 1	
DO2	Digital Output 2	
COM	Signal Common for DI, DO1, DO2	I/O cable
+	Current Output (4~20mAdc)	
-	or PROFIBUS	Shielded cable for PROFIBUS-PA
X		Excitation cable
Y	Excitation Output	(for LF622,LF622F
Е		only)
A		Signal cable
В	Signal Input	(for LF622,LF622F only)
G		(101 E1 022,E1 0221 0111y)
T+	Modbus(+)	Twisted-pair polyethylene
T-	Modbus(-)	insulated vinyl sheath cable
TG	Modbus(GND)	$(JKEV,AWG24(0.2mm^2))$

Note: Symbol of the terminal is changed as follows for Modbus.

 $DO2 \rightarrow T+$ ,  $DI \rightarrow T-$ ,  $COM \rightarrow TG$ 

### ■ Wiring Precautions

- (1) Explosion proof type flowmeters are not provided with cable glands.
  - Refer to the part Cable connection port at detector and converter.
- (2) Connect the grounding wire (IV wire 5.5mm² or more) to a good earth ground (100Ω or less ground resistance). Make the wire as short as possible. Do not use a common ground shared with other equipment where earth current may flow. An independent earth ground is recommended.
- (3) The allowable cable lengths between the detector and converter for the separate type flowmeter depend on the electrical conductivity of the object fluid. See Figure 10.
- (4) DO1, DO2 and DI use the same common terminal (COM). This COM can not be connected to other equipment which have their own ground terminal. (Power supply for connecting to DI or DO, etc...) Need to wire separately.

# ■ Wiring Precautions (PROFIBUS or Modbus)

- (1) For wiring path, avoid places near electrical equipment that may cause electromagnetic induction or electrostatic induction interference (such as a motor, transformer and wireless transmitter).
- (2) Use a PROFIBUS-PA cable or a RS485 twisted-pair cable for signal cable. In addition, make sure to use a shielded cable to improve noise resistance. Installation of signal cable in metal conduit is recommended.
- (3) General cables are designed for indoor use where cables are not exposed to humidity, rain, etc. When you install cables, make sure to check the operating conditions such as the operating temperature range of the cable by contacting its manufacturer.
- (4) When you carry out cable end treatment, use a dedicated cable stripper to avoid the core wire of the cable being nicked or damaged. In addition, for cables, be careful of allowable maximum bend diameter. (Do not allow excessive twisting or bending of cables).
- (5) Consider installing a PROFIBUS-PA arrester in the communication path of PROFBUS-PA so that the electromagnetic flowmeter will not be affected by lightning, etc.
- (6) The electromagnetic flowmeter is not equipped with terminating resistors. Use the terminating resistor unit for PROFIBUS-PA or junction box, if necessary.

- (7) Only one PROFIBUS-PA cable goes through a cable gland of the Electromagnetic Flowmeter. Please use the junction box at system configuration.
- (8) Install a terminator to flowmeter that connected to end of Modbus network.




Figure 10. Electrical Conductivity and Cable Length

#### ■ Meter size

#### To select the meter size:

See the table2 below and find meter sizes within the velocity of 0.3 to 32.8 ft/s (0.1 to 10m/s) for a specified full-scale (measuring range high limit) flow. Select one that has its full-scale velocity between 3.0 and 10 ft/s (1 and 3m/s).

**Note:** Make sure the full-scale flow rate used for the final planning stage stays within 32.8ft/s (10m/s) in terms of flow velocity.

Table 2. Flow rate and flow velocity unit: gal/min

Meter		Flow v	elocity	
size inch	0.98 ft/s	3 ft/s	10 ft/s	32.8 ft/s
20"	933.7	2,846	9,486	31,120
24"	1,344	4,098	13,660	44,820
28"	1,830	5,578	18,590	61,000
30"	2,101	6,403	21,340	70,020
32"	2,390	7,285	24,280	79,670
36"	3,025	9,221	30,740	100,800
40"	3,735	11,433	38,109	124,997
42"	4,117	12,551	41,833	137,239
48"	5,378	16,392	54,640	179,280
54"	6,806	20,747	69,143	226,883
60"	8,403	25,611	85,359	280,090
66"	10,168	31,125	103,751	340,303
72"	12,100	36,884	122,939	403,315
78"	14,201	43,285	144,284	473,411

#### ■ About establishment environment

Do not store or install the flowmeter:

- Where there is direct sunlight.
- Where excessive vibration or mechanical shock occurs.
- Where high temperature or high humidity conditions exist.
- Where corrosive atmospheres exist.
- Places that can be submerged under water.
- When placing the flowmeter temporarily on the floor, support it, i.e., with a block so that the flowmeter does not topple over.

In areas like the following, there may be the case that infrared switches do not function correctly. (If these are unavoidable, use an appropriate cover.)

- (1) Where unit (operation panel) is exposed to direct sunlight, reflection of light onto window pane and diffused light reflection.
- (2) Where smoke and steam may occur.
- (3) Where exposed to direct snow, ice or mud.

# ■ Ordering Information

- When ordering the separate type LF660/LF622 flowmeter, refer to Table 3 and 4 (Type Specification Code).
   An entry must be made for each of the columns in each of these tables.
- 2. Fluid characteristics:
  - (1) Type of fluid to be measured and its characteristics
  - (2) Fluid temperature
  - (3) Fluid pressure
  - (4) Electrical conductivity of the fluid
- 3. Measuring range
- 4. Calibration range
- 5. I/O function setting
- Ordering scope:

Flow calibration data: (required or not)

7. Other items

Specifications other than standard items

Consult a Toshiba representative when choosing materials for lining, electrodes, and grounding rings.

Table 3. Specification Code (Flange type LF664 Flowmeter)

Model number   Specification code						catio	on c	ode			G 4 4		D				
1		2 3	4	4	5	6	7	8	9		11		13	14	Contents	A	В
L		F 6	(	6	4										Electromagnetic flowmeter detector Hazardous location certification type	•	•
															Meter size		
						5	0								20" (500mm)	•	•
						6	0								24" (600mm)	•	•
						7	0								28" (700mm)	•	•
						7	5								30" (750mm)	•	•
						8	0								32" (800mm)	•	•
						9	0								36" (900mm)	•	•
						A	0								40" (1000mm)		•
						A	1								42" (1050mm)		•
						A	2								48" (1200mm)		•
						A	3								54" (1350mm)		•
						A	5								60" (1500mm)		•
						A	7		ļ	ļ				ļ	66" (1650mm)		•
						A	8	ļ							72" (1800mm)		•
						A	9								78" (1950mm)		•
															Mounting style (Note 1)(Note 3)		
								Α							Detector/Converter	•	
								ъ		<b>.</b>					combined type (LF664/LF620F)		
								В							Detector/Converter separate type (LF664/LF622F)		•
															Connection flange standard		
									С						ASME B 16.5 class 150, AWWA	•	•
															class D (Note 2)		
															Electrode material		
										K					AISI316L	•	•
										C					Titanium	0	0
										F					Hastelloy C-276 equivalent	0	0
															Lining material		
											Е				Hard rubber (NSF certified)	0	0
											N				Natural rubber	•	•
															Grounding ring material		
												A		ļ	Not provided	0	0
												В			AISI304	•	•
												С			AISI316	0	0
												Н			Hastelloy C-276 equivalent	0	0
												Е			Titanium  Dedicated professored cable	0	0
													٨		Dedicated preformed cable		
												ļ	A		Not provided	•	•
														F	Coating Polyurethane		
														E	Black tar epoxy resin		
														Ľ	Black tal cpoxy resili	0	0

Code explanation ●: Standard ○:Option

Note1: Combined type is available from 20" to 36", Separate type is available from 20" to 78"

Note2: Meter size 20"(500mm), 24"(600mm) are ASME B 16.5 class 150, Meter size 28"(700mm) and over is AWWA class D.

Note3: Potting kit is available for submersible option when selecting separate (remote) type with Hard rubber or Natural rubber lining. Please consult Toshiba for details.

Table 4. Specification Code for converters

	Μ	od	el		S	peo	ifi	ca	tic	on	Co	od	e			
1	2	3	4	5	6	7 8	3 9			1	1	1	1	Contents	LF620	LF622
	<u> </u>							(	)	1	2	3	4		type	type
L	F	6	2											Electromagnetic flowmeter converter		
				0										Combined (Integral) type	•	_
				2										Separate (Remote) type	_	•
														Purpose		
					F									cFMus class I, II, III, Division 2 approved	•	•
														Shape		
						A								Standard type with case	•	•
														Converter mounting fitting		_
						P	1							None	•	0
						(								Panel, Accessory for wall mounting (BNP material:	_	0
						I	1							SUS304)	_	0
							+	+	4					Accessory for pipe installation (BNP material: SUS304)		
							2	,						Digital input/output Digital output points 2 (DO1+DO2) +Digital input point 1		
							4	1						(DI)	_	
							L	+	+					Current output and Communication function(Note1)		
								1	ı					Current output and Communication function (Noter)  Current output + HART communication		•
								2	)					PROFIBUS communication	0	0
								3						Current output + Modbus (RS485) communication	Ö	Ö
I														Power supply(Note2)		
										1				100Vac-240Vac 50/60Hz, 110Vdc	•	•
I										2				24Vdc	0	0
	3							110Vdc	0	0						
										Instruction manual						
L											Е			English	•	•

Code explanation: ●: Standard

O: Option

—: Not available

Note 1: When PROFIBUS communication is provided, current output(4-20mA) and HART communication cannot be used. When Modbus communication is provided, digital output points 1(DO1) and digital output points(DO2), digital input point 1(DI), HART communication cannot be used. Refer Table 5 for more details.

Note2: Select 110Vdc for test report inspected under the condition of 110Vdc.

Table5. Communication functions and output selection table

Selection of Function		Availability of outputs			
Code (10 <sup>th</sup> digit)	Selected Communication	4-20mAdc	DO1	DO2	DI
1	HART	✓	✓	✓	✓
2	PROFIBUS	X	<b>✓</b>	✓	✓
3	Modbus	<b>√</b>	✓ (Note)	X	X

Code explanation: ✓: Available

X:Not Available

Note: When digital output 1 function and Modbus communication function are used at one time, TG (signal ground) of the Modbus communication function cannot be connected (2 line connection).

ISO9001 and ISO14001 are certified.

 $\mathbb{N}$ 

Misuse of this product can result in damages to property or human injury. Read related manuals carefully before using this product.

Specifications are subject to change without notice.

Printed in Japan 2014-3(TDOC)

© TOSHIBA Corporation 2015

All Rights Reserved.

http://www.toshiba.com/ind/